

Product model list : Certificate of RoHS Compliance and Certificate of EU REACH SVHC Compliance is applied.

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1	NJ-2320	Automatic Screw Feeder	2.0		
2	NJ-2323	Automatic Screw Feeder	2.3		
3	NJ-2326	Automatic Screw Feeder	2.6		
4	NJ-2330	Automatic Screw Feeder	3.0		
5	NJ-4535	Automatic Screw Feeder	3.5		
6	NJ-4540	Automatic Screw Feeder	4.0		
7	NJ-4550	Automatic Screw Feeder	5.0		
8	NJL-2320	Automatic Screw Feeder	2.0		
9	NJL-2323	Automatic Screw Feeder	2.3		
10	NJL-2326	Automatic Screw Feeder	2.6		
11	NJL-2330	Automatic Screw Feeder	3.0		
12	NJL-4535	Automatic Screw Feeder	3.5		
13	NJL-4540	Automatic Screw Feeder	4.0		
14	NJL-4550	Automatic Screw Feeder	5.0		
15	NJR-2320	Automatic Screw Feeder	2.0		
16	NJR-2323	Automatic Screw Feeder	2.3		
17	NJR-2326	Automatic Screw Feeder	2.6		
18	NJR-2330	Automatic Screw Feeder	3.0		
19	NJR-4535	Automatic Screw Feeder	3.5		
20	NJR-4540	Automatic Screw Feeder	4.0		
21	NJR-4550	Automatic Screw Feeder	5.0		
22	NJRL-2320	Automatic Screw Feeder	2.0		
23	NJRL-2323	Automatic Screw Feeder	2.3		
24	NJRL-2326	Automatic Screw Feeder	2.6		
25	NJRL-2330	Automatic Screw Feeder	3.0		
26	NJRL-4535	Automatic Screw Feeder	3.5		
27	NJRL-4540	Automatic Screw Feeder	4.0		
28	NJRL-4550	Automatic Screw Feeder	5.0		
29	NJC-2320	Automatic Screw Feeder	2.0		
30	NJC-2323	Automatic Screw Feeder	2.3		
31	NJC-2326	Automatic Screw Feeder	2.6		
32	NJC-2330	Automatic Screw Feeder	3.0		
33	NJC-4535	Automatic Screw Feeder	3.5		
34	NJC-4540	Automatic Screw Feeder	4.0		
35	NJC-4550	Automatic Screw Feeder	5.0		
36	NSB-10	Automatic Screw Feeder	1.0		
37	NSB-12	Automatic Screw Feeder	1.2		
38	NSB-14	Automatic Screw Feeder	1.4		
39	NSB-17	Automatic Screw Feeder	1.7		
40	NSB-20	Automatic Screw Feeder	2.0		
41	NSB-23	Automatic Screw Feeder	2.3		
42	NSB-26	Automatic Screw Feeder	2.6		
43	NSB-30	Automatic Screw Feeder	3.0		
44	NSR-10	Automatic Screw Feeder	1.0		
45	NSR-12	Automatic Screw Feeder	1.2		
46	NSR-14	Automatic Screw Feeder	1.4		
47	NSR-17	Automatic Screw Feeder	1.7		
48	NSR-20	Automatic Screw Feeder	2.0		
49	NSR-23	Automatic Screw Feeder	2.3		
50	NSR-26	Automatic Screw Feeder	2.6		
51	NSR-30	Automatic Screw Feeder	3.0		
52	NSBC-10	Automatic Screw Feeder	1.0		

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
53	NSBC-12	Automatic Screw Feeder	1.2		
54	NSBC-14	Automatic Screw Feeder	1.4		
55	NSBC-17	Automatic Screw Feeder	1.7		
56	NSBC-20	Automatic Screw Feeder	2.0		
57	NSBC-23	Automatic Screw Feeder	2.3		
58	NSBC-26	Automatic Screw Feeder	2.6		
59	NSBC-30	Automatic Screw Feeder	3.0		
60	NSBI-10	Automatic Screw Feeder	1.0		
61	NSBI-12	Automatic Screw Feeder	1.2		
62	NSBI-14	Automatic Screw Feeder	1.4		
63	NSBI-17	Automatic Screw Feeder	1.7		
64	NSBI-20	Automatic Screw Feeder	2.0		
65	NSBI-23	Automatic Screw Feeder	2.3		
66	NSBI-26	Automatic Screw Feeder	2.6		
67	NSBI-30	Automatic Screw Feeder	3.0		
68	NSRI-10	Automatic Screw Feeder	1.0		
69	NSRI-12	Automatic Screw Feeder	1.2		
70	NSRI-14	Automatic Screw Feeder	1.4		
71	NSRI-17	Automatic Screw Feeder	1.7		
72	NSRI-20	Automatic Screw Feeder	2.0		
73	NSRI-23	Automatic Screw Feeder	2.3		
74	NSRI-26	Automatic Screw Feeder	2.6		
75	NSRI-30	Automatic Screw Feeder	3.0		
76	NSRI-10B	Automatic Screw Feeder	1.0		
77	NSRI-12B	Automatic Screw Feeder	1.2		
78	NSRI-14B	Automatic Screw Feeder	1.4		
79	NSRI-17B	Automatic Screw Feeder	1.7		
80	NSRI-20B	Automatic Screw Feeder	2.0		
81	NSRI-23B	Automatic Screw Feeder	2.3		
82	NSRI-26B	Automatic Screw Feeder	2.6		
83	NSRI-30B	Automatic Screw Feeder	3.0		
84	OM-26M20	Automatic Screw Feeder	2.0		
85	OM-26M23	Automatic Screw Feeder	2.3		
86	OM-26M26	Automatic Screw Feeder	2.6		
87	OM-26M30	Automatic Screw Feeder	3.0		
88	OM-26M35	Automatic Screw Feeder	3.5		
89	OM-26M40	Automatic Screw Feeder	4.0		
90	OM-26M50	Automatic Screw Feeder	5.0		
91	OM-26M60	Automatic Screw Feeder	6.0		
92	OM-26R20	Automatic Screw Feeder	2.0		
93	OM-26R23	Automatic Screw Feeder	2.3		
94	OM-26R26	Automatic Screw Feeder	2.6		
95	OM-26R30	Automatic Screw Feeder	3.0		
96	OM-26R35	Automatic Screw Feeder	3.5		
97	OM-26R40	Automatic Screw Feeder	4.0		
98	OM-26R50	Automatic Screw Feeder	5.0		
99	OM-26R60	Automatic Screw Feeder	6.0		
100	OM-26RB20	Automatic Screw Feeder	2.0		
101	OM-26RB23	Automatic Screw Feeder	2.3		
102	OM-26RB26	Automatic Screw Feeder	2.6		
103	OM-26RB30	Automatic Screw Feeder	3.0		
104	OM-26RB35	Automatic Screw Feeder	3.5		
105	OM-26RB40	Automatic Screw Feeder	4.0		
106	OM-26RB50	Automatic Screw Feeder	5.0		

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
107	OM-26RB60	Automatic Screw Feeder	6.0		
108	SS-1210	Automatic Screw Feeder	1.0		
109	SS-1212	Automatic Screw Feeder	1.2		
110	SS-1214	Automatic Screw Feeder	1.4		
111	SS-1217	Automatic Screw Feeder	1.7		
112	SS-1220	Automatic Screw Feeder	2.0		
113	SS-2323	Automatic Screw Feeder	2.3		
114	SS-2326	Automatic Screw Feeder	2.6		
115	SS-2330	Automatic Screw Feeder	3.0		
116	SSI-12M10	Automatic Screw Feeder	1.0		
117	SSI-12M12	Automatic Screw Feeder	1.2		
118	SSI-12M14	Automatic Screw Feeder	1.4		
119	SSI-12M17	Automatic Screw Feeder	1.7		
120	SSI-12M20	Automatic Screw Feeder	2.0		
121	SSI-23M23	Automatic Screw Feeder	2.3		
122	SSI-23M26	Automatic Screw Feeder	2.6		
123	SSI-23M30	Automatic Screw Feeder	3.0		
124	SSI-12R10	Automatic Screw Feeder	1.0		
125	SSI-12R12	Automatic Screw Feeder	1.2		
126	SSI-12R14	Automatic Screw Feeder	1.4		
127	SSI-12R17	Automatic Screw Feeder	1.7		
128	SSI-12R20	Automatic Screw Feeder	2.0		
129	SSI-23R23	Automatic Screw Feeder	2.3		
130	SSI-23R26	Automatic Screw Feeder	2.6		
131	SSI-23R30	Automatic Screw Feeder	3.0		
132	FM-3630	Automatic Screw Feeder	3.0		
133	FM-3635	Automatic Screw Feeder	3.5		
134	FM-3640	Automatic Screw Feeder	4.0		
135	FM-3650	Automatic Screw Feeder	5.0		
136	FM-3660	Automatic Screw Feeder	6.0		
137	FME-3630	Automatic Screw Feeder	3.0		
138	FME-3635	Automatic Screw Feeder	3.5		
139	FME-3640	Automatic Screw Feeder	4.0		
140	FME-3650	Automatic Screw Feeder	5.0		
141	FME-3660	Automatic Screw Feeder	6.0		
142	LS25-HM30	Automatic Screw Feeder	3.0		
143	LS25-HM35	Automatic Screw Feeder	3.5		
144	LS25-HM40	Automatic Screw Feeder	4.0		
145	LS25-HM50	Automatic Screw Feeder	5.0		
146	LS25-HM60	Automatic Screw Feeder	6.0		
147	LS25-HM80	Automatic Screw Feeder	8.0		
148	LS50-HM30	Automatic Screw Feeder	3.0		
149	LS50-HM35	Automatic Screw Feeder	3.5		
150	LS50-HM40	Automatic Screw Feeder	4.0		
151	LS50-HM50	Automatic Screw Feeder	5.0		
152	LS50-HM60	Automatic Screw Feeder	6.0		
153	LS50-HM80	Automatic Screw Feeder	8.0		
154	LS25-HR30	Automatic Screw Feeder	3.0		
155	LS25-HR35	Automatic Screw Feeder	3.5		
156	LS25-HR40	Automatic Screw Feeder	4.0		
157	LS25-HR50	Automatic Screw Feeder	5.0		
158	LS25-HR60	Automatic Screw Feeder	6.0		
159	LS25-HR80	Automatic Screw Feeder	8.0		

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
160	LS50-HR30	Automatic Screw Feeder	3.0		
161	LS50-HR35	Automatic Screw Feeder	3.5		
162	LS50-HR40	Automatic Screw Feeder	4.0		
163	LS50-HR50	Automatic Screw Feeder	5.0		
164	LS50-HR60	Automatic Screw Feeder	6.0		
165	LS50-HR80	Automatic Screw Feeder	8.0		
166	LV25-30B	Automatic Screw Feeder	3.0	Pick up box	
167	LV25-35B	Automatic Screw Feeder	3.5	Pick up box	
168	LV25-40B	Automatic Screw Feeder	4.0	Pick up box	
169	LV25-50B	Automatic Screw Feeder	5.0	Pick up box	
170	LV25-60B	Automatic Screw Feeder	6.0	Pick up box	
171	LV25-80B	Automatic Screw Feeder	8.0	Pick up box	
172	LV50-30B	Automatic Screw Feeder	3.0	Pick up box	
173	LV50-35B	Automatic Screw Feeder	3.5	Pick up box	
174	LV50-40B	Automatic Screw Feeder	4.0	Pick up box	
175	LV50-50B	Automatic Screw Feeder	5.0	Pick up box	
176	LV50-60B	Automatic Screw Feeder	6.0	Pick up box	
177	LV50-80B	Automatic Screw Feeder	8.0	Pick up box	
178	LV25-30S	Automatic Screw Feeder	3.0	Lever take out	
179	LV25-35S	Automatic Screw Feeder	3.5	Lever take out	
180	LV25-40S	Automatic Screw Feeder	4.0	Lever take out	
181	LV25-50S	Automatic Screw Feeder	5.0	Lever take out	
182	LV25-60S	Automatic Screw Feeder	6.0	Lever take out	
183	LV25-80S	Automatic Screw Feeder	8.0	Lever take out	
184	LV50-30S	Automatic Screw Feeder	3.0	Lever take out	
185	LV50-35S	Automatic Screw Feeder	3.5	Lever take out	
186	LV50-40S	Automatic Screw Feeder	4.0	Lever take out	
187	LV50-50S	Automatic Screw Feeder	5.0	Lever take out	
188	LV50-60S	Automatic Screw Feeder	6.0	Lever take out	
189	LV50-80S	Automatic Screw Feeder	8.0	Lever take out	
190	LV25-30H	Automatic Screw Feeder	3.0	Access tray	
191	LV25-35H	Automatic Screw Feeder	3.5	Access tray	
192	LV25-40H	Automatic Screw Feeder	4.0	Access tray	
193	LV25-50H	Automatic Screw Feeder	5.0	Access tray	
194	LV25-60H	Automatic Screw Feeder	6.0	Access tray	
195	LV25-80H	Automatic Screw Feeder	8.0	Access tray	
196	LV50-30H	Automatic Screw Feeder	3.0	Access tray	
197	LV50-35H	Automatic Screw Feeder	3.5	Access tray	
198	LV50-40H	Automatic Screw Feeder	4.0	Access tray	
199	LV50-50H	Automatic Screw Feeder	5.0	Access tray	
200	LV50-60H	Automatic Screw Feeder	6.0	Access tray	
201	LV50-80H	Automatic Screw Feeder	8.0	Access tray	
202	BS-S20	Automatic Screw Feeder	2.0		
203	BS-S23	Automatic Screw Feeder	2.3		
204	BS-S26	Automatic Screw Feeder	2.6		
205	BS-S30	Automatic Screw Feeder	3.0		
206	BS-S35	Automatic Screw Feeder	3.5		
207	BS-S40	Automatic Screw Feeder	4.0		
208	BS-S50	Automatic Screw Feeder	5.0		
209	BS-S60	Automatic Screw Feeder	6.0		
210	BS-L20	Automatic Screw Feeder	2.0		
211	BS-L23	Automatic Screw Feeder	2.3		
212	BS-L26	Automatic Screw Feeder	2.6		
213	BS-L30	Automatic Screw Feeder	3.0		

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
214	BS-L35	Automatic Screw Feeder	3.5		
215	BS-L40	Automatic Screw Feeder	4.0		
216	BS-L50	Automatic Screw Feeder	5.0		
217	BS-L60	Automatic Screw Feeder	6.0		
218	BS-CS20	Automatic Screw Feeder	2.0		
219	BS-CS23	Automatic Screw Feeder	2.3		
220	BS-CS26	Automatic Screw Feeder	2.6		
221	BS-CS30	Automatic Screw Feeder	3.0		
222	BS-CS35	Automatic Screw Feeder	3.5		
223	BS-CS40	Automatic Screw Feeder	4.0		
224	BS-CS50	Automatic Screw Feeder	5.0		
225	BS-CS60	Automatic Screw Feeder	6.0		
226	BS-CL20	Automatic Screw Feeder	2.0		
227	BS-CL23	Automatic Screw Feeder	2.3		
228	BS-CL26	Automatic Screw Feeder	2.6		
229	BS-CL30	Automatic Screw Feeder	3.0		
230	BS-CL35	Automatic Screw Feeder	3.5		
231	BS-CL40	Automatic Screw Feeder	4.0		
232	BS-CL50	Automatic Screw Feeder	5.0		
233	BS-CL60	Automatic Screw Feeder	6.0		
234	BS-P10	Automatic Screw Feeder	1.0		
235	BS-P12	Automatic Screw Feeder	1.2		
236	BS-P14	Automatic Screw Feeder	1.4		
237	BS-P17	Automatic Screw Feeder	1.7		
238	BS-P20	Automatic Screw Feeder	2.0		
239	BS-P23	Automatic Screw Feeder	2.3		
240	BS-P26	Automatic Screw Feeder	2.6		
241	BS-P30	Automatic Screw Feeder	3.0		
242	SR-80	Automatic Screw Hopper			NSB,NSR,NSBI,NSRI,NSRIB
243	NJ-80	Automatic Screw Hopper			NJ,NJL,NJR,NJRL
244	NJ-80F	Automatic Screw Hopper			FM-36,FME-36
245	T-510S	Automatic Screw Hopper			NSB,NSR,NSBI,NSRI,NSRIB
246	T-510J	Automatic Screw Hopper			NJ,NJL,NJR,NJRL
247	T-510F	Automatic Screw Hopper			FM-36,FME-36
248	MHP-80M	Automatic Screw Hopper			OM-26M,OM-26R,OM-26RB
249	MHP-80S	Automatic Screw Hopper			NSB,NSR,NSBI,NSRI,NSRIB
250	MHP-80J	Automatic Screw Hopper			NJ,NJL,NJR,NJRL
251	MHP-80F	Automatic Screw Hopper			FM-36,FME-36
252	※3	Screw Delivery Tube(3m)			
253	4-40-M2.6_SCREW	D-sub Connector Mounting Screw(2pcs)			
254	AD-1200500DJ	AD-1200500DJ AC Adapter DC12V			
255	AWS8-55	Tension Spring			
256	BCLMAE01	Operation Manual BS-CL Series English			
257	BCLMAJ01	Operation Manual BS-CL Series Japanese			
258	BCSMAE01	Operation Manual BS-CS Series English			
259	BCSMAJ01	Operation Manual BS-CS Series Japanese			
260	BI10SET	Exchange Kit M1.0			
261	BI12SET	Exchange Kit M1.2			
262	BI14SET	Exchange Kit M1.4			
263	BI17SET	Exchange Kit M1.7			
264	BI20SET	Exchange Kit M2.0			
265	BI23SET	Exchange Kit M2.3			
266	BI26SET	Exchange Kit M2.6			
267	BI30SET	Exchange Kit M3.0			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
268	BSLMAE01	Operation Manual BS-L Series English			
269	BSLMAJ01	Operation Manual BS-L Series Japanese			
270	BSPMAE01	Operation Manual BS-P Series English			
271	BSPMAJ01	Operation Manual BS-P Series Japanese			
272	BSSMAE01	Operation Manual BS-S Series English			
273	BSSMAJ01	Operation Manual BS-S Series Japanese			
274	CHL-H44	Check Valve			
275	CS-1	Coated Clip(10pcs)			
276	CS-9	Coated Clip(10pcs)			
277	DKN-5G	Cable Clamp			
278	FLT01051	Claw Bracket			
279	FLT01106	Claw			
280	FLT2127#01	Rail-Left			
281	FLT2127#02	Rail-Right			
282	FM1MA01	Operation Manual FM-36 Series			
283	FM1MA02	Operation Manual FM-36 Series			
284	FR30SET	Exchange Kit M3.0			
285	FR35SET	Exchange Kit M3.5			
286	FR40SET	Exchange Kit M4.0			
287	FR50SET	Exchange Kit M5.0			
288	FR60SET	Exchange Kit M6.0			
289	G37DHC3420B012	Brushless Motor (With Harness)			
290	GP2Y0A41SK0F	Infrared Proximity Sensor			
291	GWJL4-M5	Fitting			
292	GWJL6-6	Fitting			
293	GWJL6-M5	Fitting			
294	GWS4-M5	Fitting			
295	GWS6-M5	Fitting			
296	HSC03002	Upper Cover Plate			
297	HSC03003	Feeder Holder			
298	HSC03004	Height Adj. Plate			
299	HSC03005	Lower Cover Plate			
300	HSC03010	Hopper Cover A			
301	HSC03011	Hopper Cover B (For Expansion Unit)			
302	HSC04001b#01	Main Frame (T-510J)			
303	HSC04001b#02	Main Frame (T-510S)			
304	HSC04001b#03	Main Frame (T-510F)			
305	HSC04001c#01	Main Frame (T-510J)			
306	HSC04001c#02	Main Frame (T-510S)			
307	HSC04001c#03	Main Frame (T-510F)			
308	HSC05011	Driving Belt Assy			
309	HSC05012#01	Sensor Bracket Assy (T-510F.J)			
310	HSC05012#02	Sensor Bracket Assy (T-510S)			
311	HSC05014	Stocking Hopper Assy			
312	HSC05016	DC Jack Assy			
313	HSC05017	Discharge Window Assy			
314	HSC05020	Stock Expansion Unit (With Cover)			
315	HSC05021	Mounting Base Assy (For T-510F)			
316	HSC09020#06	Distance Sensor Junction Cable			
317	HSC09021#01	Manual Pushbutton Switch (With Harness, Blue)			
318	HSC09021#02	Auto Pushbutton Switch (With Harness, Green)			
319	HSC09021#03	Screw Detector LED (With Harness)			
320	HSC09021#04	Main Motor (With Harness)			
321	HSC09021#08	Power Switch (With Harness)			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
322	HSC09021a#05	DC Jack (With Harness)			
323	HSC09021b#05	DC Jack (With Harness)			
324	HSC09022#06	Distance Sensor Junction Cable			
325	HSC09022#09	External Signal Cable			
326	HSC09023#01	Manual Pushbutton Switch (With Harness, Blue)			
327	HSC09023#02	Auto Pushbutton Switch (With Harness, Green)			
328	HSC09023#03	Screw Detector LED (With Harness)			
329	HSC09023#04	Main Motor (With Harness)			
330	HSC09023#05	DC Jack (With Harness)			
331	HSC09023#07	Hopper Level Sensor (With Harness)			
332	HSC09023#08	Power Switch (With Harness)			
333	HTBN354S3M-60	Timing Belt			
334	HTPA40S3M060-A-P14-QTC22-M3	Timing Pulley			
335	K11W	Rubber Foot			
336	K5W	Rubber Foot			
337	LFMAE01	Operation Manual LF Series English			
338	LFMAJ01	Operation Manual LF Series Japanese			
339	LSHMMAE01	Operation Manual LS-HM Series English			
340	LSHMMAJ01	Operation Manual LS-HM Series Japanese			
341	LSHRMAE01	Operation Manual LS-HR Series English			
342	LSHRMAJ01	Operation Manual LS-HR Series Japanese			
343	LVMAE01	Operation Manual LV Series English			
344	LVMAJ01	Operation Manual LV Series Japanese			
345	M4GA180-M5-E2-3-4 Spec2	Valve Assy			
346	MDC2-L-6-25-F2VD-R-FL458158	Cylinder			
347	MHP01011	Holding Bracket			
348	MHP01015	Left Cover			
349	MHP01016	Upper Cover			
350	MHP01018	Hinge Fixing Plate			
351	MHP01019	Back Adjuster (80J・80M・80S)			
352	MHP01020	Front Adjuster (80J・80M・80S)			
353	MHP01028	Cover Plate			
354	MHP01029	Drive Belt			
355	MHP01101	Magnet Arm Unit			
356	MHP01110	Sensor Bracket Assy:OM			
357	MHP01111	Output Port Assy:OM			
358	MHP01112	Sensor Bracket Assy:NJ			
359	MHP01113	Sensor Bracket Assy:NSB			
360	MHP01115	Screw Retaining Cover :NJ (80F・80J)			
361	MHP01116	Screw Retaining Cover :NSB (80S)			
362	MHP01117	Screw Retaining Cover :OM (80M)			
363	MHP01118	FM Stand			
364	MHP02001	Output Port(Right:NJ)			
365	MHP02002	Output Port(Left:NSB)			
366	MHP02011	NSB Screw Cover			
367	MHP02014	Gap Cover			
368	MHP02015	Harness Cover			
369	MHP03001	Hopper Cover (NJ) (80F・80J)			
370	MHP03002	Hopper Cover (NSB) (80S)			
371	MHP03003	Hopper Cover (OM) (80M)			
372	MHP03004	Cover Holding Plate			
373	MHP03005	Hopper Cover Window			
374	MHP09013#05	Main Motor (With Harness)			
375	MHPMA01	Operation Manual MHP Series			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z: Screw feeder model to be installed
376	NEX00001	NEX-PLC			
377	NEX09011#3-c	Interface Cable			
378	NEX09012#3-b	Interface Cable			
379	NJ00044#03	Escaper Assy M2.0			
380	NJ00044#04	Escaper Assy M2.3			
381	NJ00044#05	Escaper Assy M2.6			
382	NJ00044#06	Escaper Assy M3.0			
383	NJ00044#07	Escaper Assy M3.5			
384	NJ00044#08	Escaper Assy M4.0			
385	NJ00044#09	Escaper Assy M5.0			
386	NJ00046	DC Jack Assy			
387	NJ00048#01	Rear Cover Assy (23)			
388	NJ00048#03	Rear Cover Assy (45)			
389	NJ00049#01	Front Cover Assy (23)(With Sticker)			
390	NJ00049#02	Front Cover Assy (45)(With Sticker)			
391	NJ00074#01	Front Main Cover Assy (With Sticker)			
392	NJ00074#02	Front Main Cover Assy (With Sticker)			
393	NJ00075#01	Rear Cover Assy			
394	NJ00076#01	DC Jack Assy:NJ			
395	NJ00076#02	DC Jack Assy:NJR			
396	NJ00077#01	Escaper Unit(C) M3.0:F30			
397	NJ00077#02	Escaper Unit(C) M3.5:F35			
398	NJ00077#03	Escaper Unit(C) M4.0:F40			
399	NJ00077#04	Escaper Unit(C) M5.0:F50			
400	NJ00077#05	Escaper Unit(C) M6.0:F60			
401	NJ00079#03	Escaper Assy(C) M2.0			
402	NJ00079#04	Escaper Assy(C) M2.3			
403	NJ00079#05	Escaper Assy(C) M2.6			
404	NJ00079#06	Escaper Assy(C) M3.0			
405	NJ00079#07	Escaper Assy(C) M3.5			
406	NJ00079#08	Escaper Assy(C) M4.0			
407	NJ00079#09	Escaper Assy(C) M5.0			
408	NJ00082#01	Rear Cover Assy(Model Mix ver) (23)			
409	NJ00082#02	Rear Cover Assy(Model Mix ver) (45)			
410	NJ00083	Rear Cover Assy(Model Mix ver)			
411	NJ01000#02	Hopper Left Assy			
412	NJ01001#02	Hopper Right Assy			
413	NJ01008#03	Passing Plate #1 Assy M2.0:W2320			
414	NJ01008#04	Passing Plate #1 Assy M2.3:W2323			
415	NJ01008#05	Passing Plate #1 Assy M2.6:W2326			
416	NJ01008#06	Passing Plate #1 Assy M3.0:W2330			
417	NJ01008#07	Passing Plate #1 Assy M3.5:W4540			
418	NJ01008#08	Passing Plate #1 Assy M4.0:W4540			
419	NJ01008#09	Passing Plate #1 Assy M5.0:W4550			
420	NJ01029	Passing Plate #2:M3			
421	NJ01031	Passing Plate #2:M5			
422	NJ01042	Tension Spring			
423	NJ01042#01	Extension Spring			
424	NJ02001#02	Vibration Cam Assy			
425	NJ02001#03	Vibration Cam Assy			
426	NJ02003	DC Jack Assy			
427	NJ02004	Brush Driving Shaft Assy			
428	NJ02008	Front Cover Assy (With Sticker)			
429	NJ02013	Closing Plate: M3			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z: Screw feeder model to be installed
430	NJ02023	Brush Driving Gear 1			
431	NJ02026	Slide Plate #1			
432	NJ02035	Brush Driving Gear 2			
433	NJ02038	Brush Bracket #1			
434	NJ02039#01	Brush			
435	NJ02041#01	Extension Spring			
436	NJ02042	Cover Bracket			
437	NJ02043	Closing Plate: M5			
438	NJ03002	Driving Link Plate Assy			
439	NJ03007	Rail Holder #1 Assy			
440	NJ03008#02	Rail Holder #2 Assy (23)			
441	NJ03008#03	Rail Holder #2 Assy (45)			
442	NJ03032	Vibration Roller			
443	NJ03033	Fixing Bolt			
444	NJ03034	Rail Holder #2			
445	NJ03047	Switch Link Spring			
446	NJ03055	Vibration Spring			
447	NJ04000#02	Driving Shaft Bracket Assy			
448	NJ04004	Brush Link Assy			
449	NJ04013	Driving Gear #1			
450	NJ04014	Driving Cam - Left			
451	NJ04015	Driving Cam - Right			
452	NJ04016	Shutter Cam			
453	NJ04500#01	Driving Motor Assy			
454	NJ04501	Driving Motor Assy			
455	NJ04502	Driving Motor Assy			
456	NJ05001#02	Bit Guide Assy			
457	NJ05001#03	Bit Guide Assy			
458	NJ05015	Screw Guide #1			
459	NJ05016	Bit Guide			
460	NJ05022	Screw Guide #1			
461	NJ05030	Bit Guide Assy			
462	NJ06074#02	Counter Assy			
463	NJ06075	Stopper:M2.0-3.0			
464	NJ06076	Stopper:M3.5-5.0			
465	NJ06500	Escaper Base Left			
466	NJ06501	Escaper Base Right			
467	NJ06515	Driving Gear (Escaper)			
468	NJ06530	Bolt Plate			
469	NJ06535	Extension Spring			
470	NJ06537	Reinforcing Plate(C)			
471	NJ06550	Extension Base			
472	NJ06588#02	Extension Spring			
473	NJ06616	Left Side Cover			
474	NJ06617	Right Side Cover			
475	NJ06621	Washer			
476	NJ06640	FM Escaper Motor (With Harness)(C)			
477	NJ06643	NJR Escaper Motor (With Harness)(C)			
478	NJ08011	Front Cover			
479	NJ08013	Left Side Cover			
480	NJ08014	Right Side Cover			
481	NJ08015	Upper Cover			
482	NJ08112#01	Front Cover Assy (With Sticker)			
483	NJ08112#02	Front Cover Assy (With Sticker)			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
484	NJ09582#01	Take-Out Sensor (With Harness)			
485	NJ09582#02	Front Sensor (With Harness)			
486	NJ09582#03	Power Switch (With Harness)			
487	NJ09582#04	POWER Plug (With Harness)			
488	NJ09582#05	Main Motor (With Harness)			
489	NJ09589#01	POWER Plug (With Harness)			
490	NJ09589#02	POWER Plug (With Harness)			
491	NJ09781#03	Passing Sensor Junction Cable			
492	NJ09781#07	Escaper Motor Junction Cable			
493	NJ09781#09	Signal Harness			
494	NJ09782#01	Passing Sensor (With Harness)			
495	NJ09782#02	Passing Sensor (With Harness)			
496	NJ09782#04	Power Switch (With Harness)			
497	NJ09782#05	POWER Plug (With Harness)			
498	NJ09782#08	Escaper Motor (With Harness)			
499	NJ09782#10	Main Motor (With Harness)			
500	NJ11036	SLIDE DRIVE PLATE 1 CALKING			
501	NJ11044	TENSION SPRING			
502	NJ11047	BRUSH BRACKET			
503	NJ11051	Slide Plate #1			
504	NJ11053	Brush Driving Gear			
505	NJ11054	Escaper Base Left			
506	NJ11055	Escaper Base Right			
507	NJ1MA01	Operation Manual NJ Series			
508	NJ1MA02	Operation Manual NJ Series			
509	NJ20011	Closing Plate:M45			
510	NJ20012	Closing Plate:M23			
511	NJ20013	Passing Plate #2:M45L			
512	NJ20014	Passing Plate #2:M23L			
513	NJ20020	Stopper			
514	NJ21040#01	Vibration Cam Assy (23)			
515	NJ21040#02	Vibration Cam Assy (45)			
516	NJ21041	Rail Holder #2 Assy			
517	NJ21046#01	Passing Plate #1 Assy M2.0:WL2320			
518	NJ21046#02	Passing Plate #1 Assy M2.3:WL2323			
519	NJ21046#03	Passing Plate #1 Assy M2.6:WL2326			
520	NJ21046#04	Passing Plate #1 Assy M3.0:WL2330			
521	NJ21046#05	Passing Plate #1 Assy M3.5:WL4540			
522	NJ21046#06	Passing Plate #1 Assy M4.0:WL4540			
523	NJ21046#07	Passing Plate #1 Assy M5.0:WL4550			
524	NJ21047#01	Front Cover Assy (23)(With Sticker)			
525	NJ21047#02	Front Cover Assy (45)(With Sticker)			
526	NJ66504#01	Passing Plate #1 Assy M3.0:W3630			
527	NJ66504#02	Passing Plate #1 Assy M3.5:W3635			
528	NJ66504#03	Passing Plate #1 Assy M4.0:W3640			
529	NJ66504#04	Passing Plate #1 Assy M5.0:W3650			
530	NJ66504#05	Passing Plate #1 Assy M6.0:W3660			
531	NJ66506	Upper Cover			
532	NJB0010	HOPPER LEFT			
533	NJB0020	HOPPER RIGHT			
534	NJB0040	BRUSH Assy			
535	NJR00073#01	Escaper Cover Assy (23) (With Sticker)			
536	NJR00073#02	Escaper Cover Assy (45) (With Sticker)			
537	NJR00073#03	Escaper Cover Assy (23) (With Sticker)			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
538	NJR00073#04	Escaper Cover Assy (45) (With Sticker)			
539	NJR06506#03	Escaper:20 M2.0:E20			
540	NJR06506#04	Escaper:23 M2.3:E23			
541	NJR06506#05	Escaper:26 M2.6:E26			
542	NJR06506#06	Escaper:30 M3.0:E30			
543	NJR06506#07	Escaper:35 M3.5:E35			
544	NJR06506#08	Escaper:40 M4.0:E40			
545	NJR06506#09	Escaper:50 M5.0:E50			
546	NJR08113	Front Cover Assy (With Sticker)			
547	NJR08116#01	Escaper Cover Assy(Model Mix ver) (23)(With Sticker)			
548	NJR08116#02	Escaper Cover Assy(Model Mix ver) (45)(With Sticker)			
549	NJR08116#03	Escaper Cover Assy(Model Mix ver) (23)(With Sticker)			
550	NJR08116#04	Escaper Cover Assy(Model Mix ver) (45)(With Sticker)			
551	NJR09581#02	Front Sensor Junction Cable			
552	NJR09581#05	Escaper Motor Junction Cable			
553	NJR09581#07	Signal Harness			
554	NJR09582#01	Front Sensor (With Harness)			
555	NJR09582#03	Power Switch (With Harness)			
556	NJR09582#04	POWER Plug (With Harness)			
557	NJR09582#06	Escaper Motor (With Harness)			
558	NJR09582#08	Main Motor (With Harness)			
559	NJR1MA01	Operation Manual NJR Series			
560	NJR1MA02	Operation Manual NJR Series			
561	NSB01054	Hopper Block Assy			
562	NSB01108	Driving Holder Slit Plate			
563	NSB01122	Inclined Plate Holder Left			
564	NSB01123	Inclined Plate Holder Right			
565	NSB02051#01	Rear Hopper Wall			
566	NSB02051#02	Front Hopper Wall			
567	NSB02051#04	Brush Driving Gear Large			
568	NSB02052#01	Passing Plate:SW1017(M1.0-M1.7)			
569	NSB02052#02	Passing Plate:SW2030(M2.0-M3.0)			
570	NSB02053#01	Brush Assy (Standard)			
571	NSB02053#02	Brush Assy (Hard)(Option)			
572	NSB02054	Brush Driving Plate Assy			
573	NSB02055	Brush Shaft Assy			
574	NSB02058	Brush Driving Gear Large 3			
575	NSB02059#01	DC Jack Bracket Assy			
576	NSB02059#02	DC Jack Bracket Assy			
577	NSB02060	Rear Hopper Wall			
578	NSB02061#01	DC Jack Bracket Assy			
579	NSB02061#02	DC Jack Bracket Assy			
580	NSB02064	Brush Driving Plate Assy			
581	NSB02108	Brush Driving Plate Roller			
582	NSB02110#01	Brush (Standard)			
583	NSB02110#02	Brush (Hard)(Option)			
584	NSB02111	Brush Bracket #1			
585	NSB02112	Brush Bracket #2			
586	NSB02114	Vibration Adjusting Plate			
587	NSB02116#01	Vibration Plate			
588	NSB02122	Inclined Plate Right			
589	NSB02123	Inclined Plate Left			
590	NSB02125	Adjusting Screw			
591	NSB02127	Extension Spring			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
592	NSB02128	Polyslider (10pcs)			
593	NSB03053	Driving Shaft Bracket Assy Left			
594	NSB03054	Driving Shaft Bracket Assy Right			
595	NSB03055	Vibration Cam Assy			
596	NSB03056	Main Motor Unit:NSB			
597	NSB03107	Driving Roller			
598	NSB04053	Rail Holder Fixing Bolt			
599	NSB04119	Switch Link Spring			
600	NSB04120	Vibration Spring			
601	NSB05113	Stopper:M10 (M1.0)			
602	NSB05114	Stopper:M14 (M1.2,M1.4)			
603	NSB05115	Stopper:M30 (M1.7-M3.0)			
604	NSB06002	Bit Guide Assy			
605	NSB06003	Bit Guide Unit:NSB			
606	NSB06102	Presser Plate (Bit Guide)			
607	NSB06110	Gauge			
608	NSB07011#01	Rear Cover Assy			
609	NSB07015	Front Cover Assy (With Sticker)			
610	NSB07017	Rear Cover Assy(Model Mix ver)			
611	NSB07051	Weld Bolt (SR-80)			
612	NSB07108	Front Cover			
613	NSB07109	Left Side Cover			
614	NSB07110	Right Side Cover			
615	NSB07111	Upper Cover			
616	NSB09182#01	Take-Out Sensor (With Harness)			
617	NSB09182#02	Front Sensor (With Harness)			
618	NSB09182#03	Power Switch (With Harness)			
619	NSB09182#04	POWER Plug (With Harness)			
620	NSB09182#05	Main Motor (With Harness)			
621	NSB09183#01	POWER Plug (With Harness)			
622	NSB09183#02	POWER Plug (With Harness)			
623	NSB1MA01	Operation Manual NSB Series			
624	NSB1MA02	Operation Manual NSB Series			
625	NSBI1MA1	Operation Manual NSBI Series			
626	NSBI1MA2	Operation Manual NSBI Series			
627	NSIB2051	Rear Hopper Wall			
628	NSIB3101	Driving Shaft Bracket Supporter			
629	NSIB6103	Bit Guide Assy			
630	NSIB6109	Bit Guide Assy			
631	NSIB7020#01	Rail Assy M1.0:R10			
632	NSIB7020#02	Rail Assy M1.2:R12			
633	NSIB7020#03	Rail Assy M1.4:R14			
634	NSIB7020#04	Rail Assy M1.7:R17			
635	NSIB7020#05	Rail Assy M2.0:R120			
636	NSIB7020#06	Rail Assy M2.3:R123			
637	NSIB7020#07	Rail Assy M2.6:R126			
638	NSIB7020#08	Rail Assy M3.0:R130			
639	NSIB7102	Front Cover			
640	NSIB7107#01	Escaper Unit:NSBI M1.0			
641	NSIB7107#02	Escaper Unit:NSBI M1.2			
642	NSIB7107#03	Escaper Unit:NSBI M1.4			
643	NSIB7107#04	Escaper Unit:NSBI M1.7			
644	NSIB7107#05	Escaper Unit:NSBI M2.0			
645	NSIB7107#06	Escaper Unit:NSBI M2.3			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
646	NSIB7107#07	Escaper Unit: NSBI M2.6			
647	NSIB7107#08	Escaper Unit: NSBI M3.0			
648	NSIB7109	Escaper Driving Unit			
649	NSIB7114	Front Sensor Assy			
650	NSIB7115	Main Motor Unit			
651	NSIB7118	DC Jack Assy			
652	NSIB7120	Rear Cover Assy			
653	NSIB7121#01	Front Cover Assy (With Sticker)			
654	NSIB7121#02	Front Cover Assy (With Sticker)			
655	NSIB7200#01	Escaper Unit: NSBI2 M1.0			
656	NSIB7200#02	Escaper Unit: NSBI2 M1.2			
657	NSIB7200#03	Escaper Unit: NSBI2 M1.4			
658	NSIB7200#04	Escaper Unit: NSBI2 M1.7			
659	NSIB7200#05	Escaper Unit: NSBI2 M2.0			
660	NSIB7200#06	Escaper Unit: NSBI2 M2.3			
661	NSIB7200#07	Escaper Unit: NSBI2 M2.6			
662	NSIB7200#08	Escaper Unit: NSBI2 M3.0			
663	NSIB7201	Escaper Driving Unit			
664	NSIR6105	Presser Plate Assy			
665	NSIR7107#01	Escaper Unit: NSRI M1.0			
666	NSIR7107#02	Escaper Unit: NSRI M1.2			
667	NSIR7107#03	Escaper Unit: NSRI M1.4			
668	NSIR7107#04	Escaper Unit: NSRI M1.7			
669	NSIR7107#05	Escaper Unit: NSRI M2.0			
670	NSIR7107#06	Escaper Unit: NSRI M2.3			
671	NSIR7107#07	Escaper Unit: NSRI M2.6			
672	NSIR7107#08	Escaper Unit: NSRI M3.0			
673	NSIR7109	Escaper Driving Unit			
674	NSIR7114	Rear Cover Assy			
675	NSIR7200#01	Escaper Unit: NSRI2 M1.0			
676	NSIR7200#02	Escaper Unit: NSRI2 M1.2			
677	NSIR7200#03	Escaper Unit: NSRI2 M1.4			
678	NSIR7200#04	Escaper Unit: NSRI2 M1.7			
679	NSIR7200#05	Escaper Unit: NSRI2 M2.0			
680	NSIR7200#06	Escaper Unit: NSRI2 M2.3			
681	NSIR7200#07	Escaper Unit: NSRI2 M2.6			
682	NSIR7200#08	Escaper Unit: NSRI2 M3.0			
683	NSIR7201	Escaper Driving Unit: NSRI2			
684	NSIR7210#01	Escaper Unit: NSRI(Model Mix ver) M1.0			
685	NSIR7210#02	Escaper Unit: NSRI(Model Mix ver) M1.2			
686	NSIR7210#03	Escaper Unit: NSRI(Model Mix ver) M1.4			
687	NSIR7210#04	Escaper Unit: NSRI(Model Mix ver) M1.7			
688	NSIR7210#05	Escaper Unit: NSRI(Model Mix ver) M2.0			
689	NSIR7210#06	Escaper Unit: NSRI(Model Mix ver) M2.3			
690	NSIR7210#07	Escaper Unit: NSRI(Model Mix ver) M2.6			
691	NSIR7210#08	Escaper Unit: NSRI(Model Mix ver) M3.0			
692	NSIR7211	Escaper Driving Unit(Model Mix ver)			
693	NSIR7403	Main Motor Unit: NSRI-B			
694	NSIR7404	Front Cover Assy (With Sticker)			
695	NSIR7406	Rear Cover Assy			
696	NSIR7409	Sticker: NSRI-B			
697	NSIR7411	Front Cover: B Type			
698	NSIR7412	Left Cover (OHTAKE Blue)			
699	NSIR7413	Right Cover (OHTAKE Blue)			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
700	NSIR9104#02	Sensor Junction Cable-Origin Sensor			
701	NSIR9104#04	LED Junction Cable			
702	NSIR9104#06	Switch Junction Cable			
703	NSIR9104#08	Signal Junction Cable			
704	NSIR9104#09	Motor Junction Cable			
705	NSIR9104#11	Power Junction Cable			
706	NSIR9104#12	Jumper Connector			
707	NSIR9104#14	Sensor Junction Cable-Front Sensor			
708	NSIR9104#16	Signal Harness			
709	NSIR9105#03	Front Sensor Detector LED (With Harness)			
710	NSIR9105#05	Power Switch (With Harness)			
711	NSIR9105#07	Power Plug (With Harness)			
712	NSIR9105#13	Front Sensor (With Harness)			
713	NSIR9105#15	Main Motor (With Harness)			
714	NSN02005	Brush Assy			
715	NSN02006	Hopper Brock Assy			
716	NSN02103	Inclined Plate Holder "B"			
717	NSN02107	Brush			
718	NSN02108	Brush Bracket "B"			
719	NSN02114	Inclined Plate			
720	NSN03001	Driving Gear Unit:SS			
721	NSN03102	Driving Gear			
722	NSN03114	Brush Driving Belt			
723	NSN04004	Full Sensor Unit:SS12			
724	NSN04005	Front Sensor Unit			
725	NSN04006	Solenoid Unit			
726	NSN06001	Bit Guide Assy			
727	NSN08003	Middle Cover Assy (With Sticker)			
728	NSN08005#01	Front Cover Assy:SS12 (With Sticker)			
729	NSN08005#02	Front Cover Assy:SS23 (With Sticker)			
730	NSN08006	Rear Cover Assy			
731	NSN08104	Cover - Left			
732	NSN08105	Cover - Right			
733	NSN08106	Upper Cover			
734	NSN08201	Driver			
735	NSN09102#01	Full Sensor (With Harness)			
736	NSN09102#02	Take-Out Sensor (With Harness)			
737	NSN09102#03	Front Sensor (With Harness)			
738	NSN09102#04	Power Switch (With Harness)			
739	NSN09102#05	Power Plug (With Harness)			
740	NSN09102#07	Main Motor (With Harness)			
741	NSN1MA01	Operation Manual SS Series			
742	NSN22001	Brush:23			
743	NSN22005	Brush Assy			
744	NSN22006	Hopper Brock Assy (23)			
745	NSN24004	Full Sensor Unit:SS23			
746	NSR02056	Vibration Adjusting Plate Assy			
747	NSR06004	Presser Plate Unit:NSR			
748	NSR06601	Presser Plate:E Type			
749	NSR07012#01	Rear Cover Assy			
750	NSR07016	Front Cover Assy (With Sticker)			
751	NSR07018	Rear Cover Assy(Model Mix ver)			
752	NSR07601	Front Cover:E Type			
753	NSR07604#01	Left Side Cover			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
754	NSR07604#02	Left Side Cover			
755	NSR07605#01	Right Side Cover			
756	NSR07605#02	Right Side Cover			
757	NSR08001#01	Escaper Unit:NSR M1.0			
758	NSR08001#02	Escaper Unit:NSR M1.2			
759	NSR08001#03	Escaper Unit:NSR M1.4			
760	NSR08001#04	Escaper Unit:NSR M1.7			
761	NSR08001#05	Escaper Unit:NSR M2.0			
762	NSR08001#06	Escaper Unit:NSR M2.3			
763	NSR08001#07	Escaper Unit:NSR M2.6			
764	NSR08001#08	Escaper Unit:NSR M3.0			
765	NSR08004#01	Escaper Unit:NSR (C) M1.0			
766	NSR08004#02	Escaper Unit:NSR (C) M1.2			
767	NSR08004#03	Escaper Unit:NSR (C) M1.4			
768	NSR08004#04	Escaper Unit:NSR (C) M1.7			
769	NSR08004#05	Escaper Unit:NSR (C) M2.0			
770	NSR08004#06	Escaper Unit:NSR (C) M2.3			
771	NSR08004#07	Escaper Unit:NSR (C) M2.6			
772	NSR08004#08	Escaper Unit:NSR (C) M3.0			
773	NSR08053	NSR Escaper Motor (With Harness)(C)			
774	NSR08616	Bolt Plate			
775	NSR08618#02	Escaper:10 M1.0:SE10			
776	NSR08618#03	Escaper:12 M1.2:SE12			
777	NSR08618#04	Escaper:14 M1.4:SE14			
778	NSR08618#05	Escaper:17 M1.7:SE17			
779	NSR08618#06	Escaper:20 M2.0:SE20			
780	NSR08618#07	Escaper:23 M2.3:SE23			
781	NSR08618#08	Escaper:26 M2.6:SE26			
782	NSR08618#09	Escaper:30 M3.0:SE30			
783	NSR08620#02	Extension Spring			
784	NSR08621	Light Receiver Slit Plate			
785	NSR09681#02	Front Sensor Junction Cable			
786	NSR09681#04	Power Switch Junction Cable			
787	NSR09681#06	Escaper Motor Junction Cable			
788	NSR09681#08	Signal Harness			
789	NSR09682#01	Front Sensor (With Harness)			
790	NSR09682#03	Power Switch (With Harness)			
791	NSR09682#05	POWER Plug (With Harness)			
792	NSR09682#07	Escaper Motor (With Harness)			
793	NSR1MA01	Operation Manual NSR Series			
794	NSR1MA02	Operation Manual NSR Series			
795	NSRI1MA1	Operation Manual NSRI Series			
796	NSRI1MA2	Operation Manual NSRI Series			
797	NSRI-BMA1	Operation Manual NSRI-B Series			
798	OMM1MA01	Operation Manual OM-26M Series			
799	OMM1MA02	Operation Manual OM-26M Series			
800	OMM20SET	Exchange Kit M2.0			
801	OMM23SET	Exchange Kit M2.3			
802	OMM26SET	Exchange Kit M2.6			
803	OMM30SET	Exchange Kit M3.0			
804	OMM35SET	Exchange Kit M3.5			
805	OMM40SET	Exchange Kit M4.0			
806	OMM50SET	Exchange Kit M5.0			
807	OMM60SET	Exchange Kit M6.0			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
808	OMR1MA01	Operation Manual OM-26R Series			
809	OMR1MA02	Operation Manual OM-26R Series			
810	OMR20SET	Exchange Kit M2.0			
811	OMR20SET2	Exchange Kit M2.0			
812	OMR23SET	Exchange Kit M2.3			
813	OMR23SET2	Exchange Kit M2.3			
814	OMR26SET	Exchange Kit M2.6			
815	OMR26SET2	Exchange Kit M2.6			
816	OMR30SET	Exchange Kit M3.0			
817	OMR30SET2	Exchange Kit M3.0			
818	OMR35SET	Exchange Kit M3.5			
819	OMR35SET2	Exchange Kit M3.5			
820	OMR40SET	Exchange Kit M4.0			
821	OMR40SET2	Exchange Kit M4.0			
822	OMR50SET	Exchange Kit M5.0			
823	OMR50SET2	Exchange Kit M5.0			
824	OMR60SET	Exchange Kit M6.0			
825	OMR60SET2	Exchange Kit M6.0			
826	OMRBMA01	Operation Manual OM-26RB Series			
827	ON-0006	Bottom Plate			
828	ON-0015	Motor Base Plate			
829	ON-0019	Switch Mounting Plate			
830	ON-0020	PCB Cover			
831	ON-0022	Hopper Top Cover			
832	ON-0023	NSR-Type Outlet Ramp Cover			
833	ON-0024	NJR-Type Outlet Ramp Cover			
834	ON-0026b	SR-Type Sensor Support A			
835	ON-0026c	SR-Type Sensor Support A			
836	ON-0027b	NJ-Type Sensor Support A			
837	ON-0027c	NJ-Type Sensor Support A			
838	ON-0036	NSR-Type Screw Outlet Ramp			
839	ON-0037	NJR-Type Screw Outlet Ramp			
840	ON-0061	Drive Belt			
841	ON-0081	NJ-Type Sensor Holder Assy			
842	ON-0082	SR-Type Sensor Holder Assy			
843	ON-0083	Center Motor Plate Assy			
844	ON-0084	Timing Pulley Assy			
845	ON-0094	Motor Plate Assy			
846	ON-0095	Rotary Drum Assy			
847	ON-0096c	Sensor Arm Assy			
848	ON-0096d	Sensor Arm Assy			
849	ON-0097b	Sensor Arm Assy			
850	ON-0097c	Sensor Arm Assy			
851	ON-0098	Safety Cover Assy (NJ-80/NJ-80F)			
852	ON-0099	Safety Cover Assy (SR-80)			
853	ON-0100	Mounting Base Assy (for NJ-80F ONLY)			
854	ON-0103#01	Rear Cover Assy (NJ-80)			
855	ON-0103#02	Rear Cover Assy (SR-80)			
856	ON-0103#03	Rear Cover Assy (NJ-80F)			
857	ONF1MA01b	Operation Manual NJ-80/SR-80 Series			
858	ONF1MA01c	Operation Manual NJ-80/SR-80 Series			
859	ONT1MA01a	Operation Manual T-510 Series			
860	ONT1MA01b	Operation Manual T-510 Series			
861	PBS00007	Cover Plate			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z: Screw feeder model to be installed
862	PBS00014	Upper Cover			
863	PBS00053	Side Plate Reinforcement Plate 2			
864	PBS00062	Magnet Pully Washer			
865	PBS00072	Scraper Left			
866	PBS00073	Scraper Right			
867	PBS00086	Upper Cover			
868	PBS00101	Brush Driving Gear Large			
869	PBS00160	Presser Plate Main			
870	PBS00168	Presser Plate Part			
871	PBS00220##**	Short Pipe			
872	PBS00220##100	Short Pipe φ10.0			
873	PBS00220##110	Short Pipe φ11.0			
874	PBS00220##120	Short Pipe φ12.0			
875	PBS00220##130	Short Pipe φ13.0			
876	PBS00220##140	Short Pipe φ14.0			
877	PBS00220##150	Short Pipe φ15.0			
878	PBS00220##40	Short Pipe φ4.0			
879	PBS00220##45	Short Pipe φ4.5			
880	PBS00220##50	Short Pipe φ5.0			
881	PBS00220##55	Short Pipe φ5.5			
882	PBS00220##60	Short Pipe φ6.0			
883	PBS00220##65	Short Pipe φ6.5			
884	PBS00220##70	Short Pipe φ7.0			
885	PBS00220##75	Short Pipe φ7.5			
886	PBS00220##80	Short Pipe φ8.0			
887	PBS00220##90	Short Pipe φ9.0			
888	PBS00221	Pusher			
889	PBS00293	Presser Plate			
890	PBS00302	Left Cover			
891	PBS00329	Guide Plate Right			
892	PBS00342	Right Cover Assy			
893	PBS00526	Driving Cam			
894	PBS00685	Side Cover Left			
895	PBS00687	Side Cover Right			
896	PBS00726	Bolt Receiving Plate			
897	PBS00740#01	Secsor Cover			
898	PBS00740#02	Secsor Cover			
899	PBS00741	Board Cover Assy			
900	PBS09564#04	Power Switch (with Haress)			
901	PBS09564#05	Power Plug (With Harness)			
902	PBS09564#09	Screw out Sensor (With Harness)			
903	PBS09564#10	Signal Relay Cable			
904	PBS09564#23	Feeding Activation Switch (With Harness)			
905	PBS09565#08	Front Sensor (With Harness)			
906	PBS09565#09	Screw out Sensor (With Harness)			
907	PBS09565#10	Signal relay cable			
908	PBS09565#25	Power Plug (With Harness)			
909	PBS09565#26	Feeding Activation Switch (With Harness)			
910	PBS09565#28	Slide Cylinder Sensor(With Harness)			
911	PBS09567#01	Screw Count Sensor (With Harness)			
912	PBS09567#02	Unloading Lever Close Sensor (With Harness)			
913	PBS09567#03	Unloading Lever Open Sensor (With Harness)			
914	PBS09567#05	LED Harness			
915	PBS09567#06	Counter Relay Harness			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
916	PBSB0003	Motor Bracket Unit			
917	PBSB0039	Twin Magnet Drive			
918	PBSB1000#**	Shoot Box			
919	PBSB1000#01	Shoot Box φ23			
920	PBSB1000#02	Shoot Box φ22			
921	PBSB1000#03	Shoot Box φ21			
922	PBSB1000#04	Shoot Box φ20			
923	PBSB1000#05	Shoot Box φ19			
924	PBSB1000#06	Shoot Box φ16			
925	PBSB1000#07	Shoot Box φ17			
926	PBSB1000#08	Shoot Box φ12			
927	PBSB1000#09	Shoot Box φ10			
928	PBSB1000#10	Shoot Box φ8			
929	PBSB1000#11	Shoot Box φ6			
930	PBSB1000#12	Shoot Box φ5			
931	PBSB1014	Slide Unit for Shoot Box			
932	PBSB1015	Unloading Lever Unit			
933	PBSB1659	Motor Bracket Unit			
934	PBSB1664	Dust Box			
935	PBSB1673#01	Rail Assy M2.0			
936	PBSB1673#02	Rail Assy M2.3			
937	PBSB1673#03	Rail Assy M2.6			
938	PBSB1673#04	Rail Assy M3.0			
939	PBSB1673#05	Rail Assy M3.5			
940	PBSB1673#06	Rail Assy M4.0			
941	PBSB1673#07	Rail Assy M5.0			
942	PBSB1673#08	Rail Assy M6.0			
943	PBSB1766	Rear Cover Assy			
944	PBSB1767	Front Cover Assy			
945	PBSB1803	Block "C" Assy			
946	PBSB1808	Base Assy			
947	PBSB1866	Rear Cover Assy			
948	PBSB1867	Front Cover Assy			
949	PBSB4002	Magnet Arm Assy			
950	PBSB4005	Motor Bracket Unit			
951	PBSB4014	Front Cover Assy			
952	PBSB4015	Rear Cover Assy			
953	PBSB4016	Side Cover Left Assy			
954	PBSB4017	Side Cover Right Assy			
955	PBSB4020#01	Rail Assy M2.0			
956	PBSB4020#02	Rail Assy M2.3			
957	PBSB4020#03	Rail Assy M2.6			
958	PBSB4020#04	Rail Assy M3.0			
959	PBSB4020#05	Rail Assy M3.5			
960	PBSB4020#06	Rail Assy M4.0			
961	PBSB4020#07	Rail Assy M5.0			
962	PBSB4020#08	Rail Assy M6.0			
963	PBSB4022	Speed Controller Bracket Assy			
964	PBSB4032	Front Cover Assy			
965	PBSB4033	Rear Cover Assy			
966	PBSB4051	Front Sensor Assy			
967	PBSB4056#**	Push Cylinder Unit			
968	PBSB4056#01	Push Cylinder Unit φ20			
969	PBSB4056#02	Push Cylinder Unit φ23			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
970	PBSB4056#03	Push Cylinder Unit φ26			
971	PBSB4056#04	Push Cylinder Unit φ30			
972	PBSB4056#05	Push Cylinder Unit φ35			
973	PBSB4056#06	Push Cylinder Unit φ40			
974	PBSB4056#07	Push Cylinder Unit φ50			
975	PBSB4056#08	Push Cylinder Unit φ60			
976	PBSB4057	Slide Cylinder Unit			
977	PBSB4065#**	BS Slide Unit			
978	PBSB4065#01##100	BS Slide Unit φ30-φ10.0			
979	PBSB4065#01##110	BS Slide Unit φ30-φ11.0			
980	PBSB4065#01##120	BS Slide Unit φ30-φ12.0			
981	PBSB4065#01##40	BS Slide Unit φ30-φ4.0			
982	PBSB4065#01##45	BS Slide Unit φ30-φ4.5			
983	PBSB4065#01##50	BS Slide Unit φ30-φ5.0			
984	PBSB4065#01##55	BS Slide Unit φ30-φ5.5			
985	PBSB4065#01##60	BS Slide Unit φ30-φ6.0			
986	PBSB4065#01##65	BS Slide Unit φ30-φ6.5			
987	PBSB4065#01##70	BS Slide Unit φ30-φ7.0			
988	PBSB4065#01##75	BS Slide Unit φ30-φ7.5			
989	PBSB4065#01##80	BS Slide Unit φ30-φ8.0			
990	PBSB4065#01##90	BS Slide Unit φ30-φ9.0			
991	PBSB4065#02##100	BS Slide Unit φ35-φ10.0			
992	PBSB4065#02##110	BS Slide Unit φ35-φ11.0			
993	PBSB4065#02##120	BS Slide Unit φ35-φ12.0			
994	PBSB4065#02##40	BS Slide Unit φ35-φ4.0			
995	PBSB4065#02##45	BS Slide Unit φ35-φ4.5			
996	PBSB4065#02##50	BS Slide Unit φ35-φ5.0			
997	PBSB4065#02##55	BS Slide Unit φ35-φ5.5			
998	PBSB4065#02##60	BS Slide Unit φ35-φ6.0			
999	PBSB4065#02##65	BS Slide Unit φ35-φ6.5			
1000	PBSB4065#02##70	BS Slide Unit φ35-φ7.0			
1001	PBSB4065#02##75	BS Slide Unit φ35-φ7.5			
1002	PBSB4065#02##80	BS Slide Unit φ35-φ8.0			
1003	PBSB4065#02##90	BS Slide Unit φ35-φ9.0			
1004	PBSB4065#03##100	BS Slide Unit φ40-φ10.0			
1005	PBSB4065#03##110	BS Slide Unit φ40-φ11.0			
1006	PBSB4065#03##120	BS Slide Unit φ40-φ12.0			
1007	PBSB4065#03##40	BS Slide Unit φ40-φ4.0			
1008	PBSB4065#03##45	BS Slide Unit φ40-φ4.5			
1009	PBSB4065#03##50	BS Slide Unit φ40-φ5.0			
1010	PBSB4065#03##55	BS Slide Unit φ40-φ5.5			
1011	PBSB4065#03##60	BS Slide Unit φ40-φ6.0			
1012	PBSB4065#03##65	BS Slide Unit φ40-φ6.5			
1013	PBSB4065#03##70	BS Slide Unit φ40-φ7.0			
1014	PBSB4065#03##75	BS Slide Unit φ40-φ7.5			
1015	PBSB4065#03##80	BS Slide Unit φ40-φ8.0			
1016	PBSB4065#03##90	BS Slide Unit φ40-φ9.0			
1017	PBSB4065#04##100	BS Slide Unit φ50-φ10.0			
1018	PBSB4065#04##110	BS Slide Unit φ50-φ11.0			
1019	PBSB4065#04##120	BS Slide Unit φ50-φ12.0			
1020	PBSB4065#04##40	BS Slide Unit φ50-φ4.0			
1021	PBSB4065#04##45	BS Slide Unit φ50-φ4.5			
1022	PBSB4065#04##50	BS Slide Unit φ50-φ5.0			
1023	PBSB4065#04##55	BS Slide Unit φ50-φ5.5			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1024	PBSB4065#04##60	BS Slide Unit φ50-φ6.0			
1025	PBSB4065#04##65	BS Slide Unit φ50-φ6.5			
1026	PBSB4065#04##70	BS Slide Unit φ50-φ7.0			
1027	PBSB4065#04##75	BS Slide Unit φ50-φ7.5			
1028	PBSB4065#04##80	BS Slide Unit φ50-φ8.0			
1029	PBSB4065#04##90	BS Slide Unit φ50-φ9.0			
1030	PBSB4065#05##100	BS Slide Unit φ60-φ10.0			
1031	PBSB4065#05##110	BS Slide Unit φ60-φ11.0			
1032	PBSB4065#05##120	BS Slide Unit φ60-φ12.0			
1033	PBSB4065#05##40	BS Slide Unit φ60-φ4.0			
1034	PBSB4065#05##45	BS Slide Unit φ60-φ4.5			
1035	PBSB4065#05##50	BS Slide Unit φ60-φ5.0			
1036	PBSB4065#05##55	BS Slide Unit φ60-φ5.5			
1037	PBSB4065#05##60	BS Slide Unit φ60-φ6.0			
1038	PBSB4065#05##65	BS Slide Unit φ60-φ6.5			
1039	PBSB4065#05##70	BS Slide Unit φ60-φ7.0			
1040	PBSB4065#05##75	BS Slide Unit φ60-φ7.5			
1041	PBSB4065#05##80	BS Slide Unit φ60-φ8.0			
1042	PBSB4065#05##90	BS Slide Unit φ60-φ9.0			
1043	PBSB4066##**	BS L-Port Assy			
1044	PBSB4066##100	BS L-Port Assy φ10.0			
1045	PBSB4066##110	BS L-Port Assy φ11.0			
1046	PBSB4066##120	BS L-Port Assy φ12.0			
1047	PBSB4066##40	BS L-Port Assy φ4.0			
1048	PBSB4066##45	BS L-Port Assy φ4.5			
1049	PBSB4066##50	BS L-Port Assy φ5.0			
1050	PBSB4066##55	BS L-Port Assy φ5.5			
1051	PBSB4066##60	BS L-Port Assy φ6.0			
1052	PBSB4066##65	BS L-Port Assy φ6.5			
1053	PBSB4066##70	BS L-Port Assy φ7.0			
1054	PBSB4066##75	BS L-Port Assy φ7.5			
1055	PBSB4066##80	BS L-Port Assy φ8.0			
1056	PBSB4066##90	BS L-Port Assy φ9.0			
1057	PBSB4075##**##**	BSL Slide Unit			
1058	PBSB4075#01##100	BSL Slide Unit φ30-φ10.0			
1059	PBSB4075#01##110	BSL Slide Unit φ30-φ11.0			
1060	PBSB4075#01##120	BSL Slide Unit φ30-φ12.0			
1061	PBSB4075#01##40	BSL Slide Unit φ30-φ4.0			
1062	PBSB4075#01##45	BSL Slide Unit φ30-φ4.5			
1063	PBSB4075#01##50	BSL Slide Unit φ30-φ5.0			
1064	PBSB4075#01##55	BSL Slide Unit φ30-φ5.5			
1065	PBSB4075#01##60	BSL Slide Unit φ30-φ6.0			
1066	PBSB4075#01##65	BSL Slide Unit φ30-φ6.5			
1067	PBSB4075#01##70	BSL Slide Unit φ30-φ7.0			
1068	PBSB4075#01##75	BSL Slide Unit φ30-φ7.5			
1069	PBSB4075#01##80	BSL Slide Unit φ30-φ8.0			
1070	PBSB4075#01##90	BSL Slide Unit φ30-φ9.0			
1071	PBSB4075#02##100	BSL Slide Unit φ35-φ10.0			
1072	PBSB4075#02##110	BSL Slide Unit φ35-φ11.0			
1073	PBSB4075#02##120	BSL Slide Unit φ35-φ12.0			
1074	PBSB4075#02##40	BSL Slide Unit φ35-φ4.0			
1075	PBSB4075#02##45	BSL Slide Unit φ35-φ4.5			
1076	PBSB4075#02##50	BSL Slide Unit φ35-φ5.0			
1077	PBSB4075#02##55	BSL Slide Unit φ35-φ5.5			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z: Screw feeder model to be installed
1078	PBSB4075#02##60	BSL Slide Unit φ35-φ6.0			
1079	PBSB4075#02##65	BSL Slide Unit φ35-φ6.5			
1080	PBSB4075#02##70	BSL Slide Unit φ35-φ7.0			
1081	PBSB4075#02##75	BSL Slide Unit φ35-φ7.5			
1082	PBSB4075#02##80	BSL Slide Unit φ35-φ8.0			
1083	PBSB4075#02##90	BSL Slide Unit φ35-φ9.0			
1084	PBSB4075#03##100	BSL Slide Unit φ40-φ10.0			
1085	PBSB4075#03##110	BSL Slide Unit φ40-φ11.0			
1086	PBSB4075#03##120	BSL Slide Unit φ40-φ12.0			
1087	PBSB4075#03##40	BSL Slide Unit φ40-φ4.0			
1088	PBSB4075#03##45	BSL Slide Unit φ40-φ4.5			
1089	PBSB4075#03##50	BSL Slide Unit φ40-φ5.0			
1090	PBSB4075#03##55	BSL Slide Unit φ40-φ5.5			
1091	PBSB4075#03##60	BSL Slide Unit φ40-φ6.0			
1092	PBSB4075#03##65	BSL Slide Unit φ40-φ6.5			
1093	PBSB4075#03##70	BSL Slide Unit φ40-φ7.0			
1094	PBSB4075#03##75	BSL Slide Unit φ40-φ7.5			
1095	PBSB4075#03##80	BSL Slide Unit φ40-φ8.0			
1096	PBSB4075#03##90	BSL Slide Unit φ40-φ9.0			
1097	PBSB4075#04##100	BSL Slide Unit φ50-φ10.0			
1098	PBSB4075#04##110	BSL Slide Unit φ50-φ11.0			
1099	PBSB4075#04##120	BSL Slide Unit φ50-φ12.0			
1100	PBSB4075#04##40	BSL Slide Unit φ50-φ4.0			
1101	PBSB4075#04##45	BSL Slide Unit φ50-φ4.5			
1102	PBSB4075#04##50	BSL Slide Unit φ50-φ5.0			
1103	PBSB4075#04##55	BSL Slide Unit φ50-φ5.5			
1104	PBSB4075#04##60	BSL Slide Unit φ50-φ6.0			
1105	PBSB4075#04##65	BSL Slide Unit φ50-φ6.5			
1106	PBSB4075#04##70	BSL Slide Unit φ50-φ7.0			
1107	PBSB4075#04##75	BSL Slide Unit φ50-φ7.5			
1108	PBSB4075#04##80	BSL Slide Unit φ50-φ8.0			
1109	PBSB4075#04##90	BSL Slide Unit φ50-φ9.0			
1110	PBSB4075#05##100	BSL Slide Unit φ60-φ10.0			
1111	PBSB4075#05##110	BSL Slide Unit φ60-φ11.0			
1112	PBSB4075#05##120	BSL Slide Unit φ60-φ12.0			
1113	PBSB4075#05##40	BSL Slide Unit φ60-φ4.0			
1114	PBSB4075#05##45	BSL Slide Unit φ60-φ4.5			
1115	PBSB4075#05##50	BSL Slide Unit φ60-φ5.0			
1116	PBSB4075#05##55	BSL Slide Unit φ60-φ5.5			
1117	PBSB4075#05##60	BSL Slide Unit φ60-φ6.0			
1118	PBSB4075#05##65	BSL Slide Unit φ60-φ6.5			
1119	PBSB4075#05##70	BSL Slide Unit φ60-φ7.0			
1120	PBSB4075#05##75	BSL Slide Unit φ60-φ7.5			
1121	PBSB4075#05##80	BSL Slide Unit φ60-φ8.0			
1122	PBSB4075#05##90	BSL Slide Unit φ60-φ9.0			
1123	PBSB4076###**	BSL L-Port Assy			
1124	PBSB4076##100	BSL L-Port Assy φ10.0			
1125	PBSB4076##110	BSL L-Port Assy φ11.0			
1126	PBSB4076##120	BSL L-Port Assy φ12.0			
1127	PBSB4076##40	BSL L-Port Assy φ4.0			
1128	PBSB4076##45	BSL L-Port Assy φ4.5			
1129	PBSB4076##50	BSL L-Port Assy φ5.0			
1130	PBSB4076##55	BSL L-Port Assy φ5.5			
1131	PBSB4076##60	BSL L-Port Assy φ6.0			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1132	PBSB4076##65	BSL L-Port Assy φ6.5			
1133	PBSB4076##70	BSL L-Port Assy φ7.0			
1134	PBSB4076##75	BSL L-Port Assy φ7.5			
1135	PBSB4076##80	BSL L-Port Assy φ8.0			
1136	PBSB4076##90	BSL L-Port Assy φ9.0			
1137	PBSB4104	Block "B" Assy			
1138	PBSB4109	Base Assy			
1139	PBSB4122	Base Assy			
1140	PLM00008	Scraper Left			
1141	PLM00037	Brush Shaft			
1142	PLM00044	Cover Switch Bracket			
1143	PLM00069#04	Escaper(for LV) M3.0			
1144	PLM00069#05	Escaper(for LV) M3.5			
1145	PLM00069#06	Escaper(for LV) M4.0			
1146	PLM00069#07	Escaper(for LV) M5.0			
1147	PLM00069#08	Escaper(for LV) M6.0			
1148	PLM00069#09	Escaper(for LV) M8.0			
1149	PLM00076	Separator Guide			
1150	PLM00101	Side Panel			
1151	PLM00103	Front Cover			
1152	PLM00104	Rear Panel			
1153	PLM00105	TLLB3200 Bracket			
1154	PLM00108	Scraper Right			
1155	PLM00117	Holding Plate			
1156	PLM00119	Screw Catch Box			
1157	PLM00126	Scraper Nut Plate			
1158	PLM00128	Separator Guide Spacer			
1159	PLM00140	Post			
1160	PLM00142	Brush Driving Gear Large(with Flange)			
1161	PLM00147	Upper Lid			
1162	PLM00149	Tension Spring:Escaper			
1163	PLM00151#02	Screw Guide M3.0			
1164	PLM00151#03	Screw Guide M3.5/M4.0			
1165	PLM00151#04	Screw Guide M5.0/M6.0			
1166	PLM00151#05	Screw Guide M8.0			
1167	PLM00151#06	Screw Guide M9.0/M10.0			
1168	PLM00167	Screw Support Block			
1169	PLM00225	Main Motor Pulley			
1170	PLM00500	Stopper Plate			
1171	PLM00509#01	Escaper(for LS) M2.0			
1172	PLM00509#02	Escaper(for LS) M2.3			
1173	PLM00509#03	Escaper(for LS) M2.6			
1174	PLM00509#04	Escaper(for LS) M3.0			
1175	PLM00509#05	Escaper(for LS) M3.5			
1176	PLM00509#06	Escaper(for LS) M4.0			
1177	PLM00509#07	Escaper(for LS) M5.0			
1178	PLM00509#08	Escaper(for LS) M6.0			
1179	PLM00509#09	Escaper(for LS) M8.0			
1180	PLM00531	Screw Guide 1			
1181	PLM00534#01	Escaper Guide Left M2.0			
1182	PLM00534#02	Escaper Guide Left M2.3			
1183	PLM00534#03	Escaper Guide Left M2.6			
1184	PLM00534#04	Escaper Guide Left M3.0			
1185	PLM00534#05	Escaper Guide Left M3.5			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1186	PLM00534#06	Escaper Guide Left M4.0			
1187	PLM00534#07	Escaper Guide Left M5.0			
1188	PLM00534#08	Escaper Guide Left M6.0			
1189	PLM00534#09	Escaper Guide Left M8.0			
1190	PLM00535#01	Escaper Guide Right M2.0			
1191	PLM00535#02	Escaper Guide Right M2.3			
1192	PLM00535#03	Escaper Guide Right M2.6			
1193	PLM00535#04	Escaper Guide Right M3.0			
1194	PLM00535#05	Escaper Guide Right M3.5			
1195	PLM00535#06	Escaper Guide Right M4.0			
1196	PLM00535#07	Escaper Guide Right M5.0			
1197	PLM00535#08	Escaper Guide Right M6.0			
1198	PLM00535#09	Escaper Guide Right M8.0			
1199	PLM00536	Stopper for Torsion Spring			
1200	PLM00537	Stopper			
1201	PLM00540#04	Escaper Guide Left M3.0			
1202	PLM00540#05	Escaper Guide Left M3.5			
1203	PLM00540#06	Escaper Guide Left M4.0			
1204	PLM00540#07	Escaper Guide Left M5.0			
1205	PLM00540#08	Escaper Guide Left M6.0			
1206	PLM00540#09	Escaper Guide Left M8.0			
1207	PLM00541	Escaper Guide Right			
1208	PLM00543	Side Panel			
1209	PLM00544	Front Sub Cover			
1210	PLM00552	Screw Guide			
1211	PLM00554	Front Cover			
1212	PLM00557#01	Torsion Spring:LS			
1213	PLM00557#02	Torsion Spring:LF			
1214	PLM00612	Storage Box Cover			
1215	PLM00615	Front Cover:Spec S			
1216	PLM00617	LV Front Cover:Spec S			
1217	PLM00619	Storage Box			
1218	PLM00621	Sensor Bracket			
1219	PLM04001	Front Cover,Under			
1220	PLM04104	Front Cover,Upper			
1221	PLM04105	Side Cover			
1222	PLM04106	Rear Panel			
1223	PLM04107	Front Cover,Inside			
1224	PLM04108	Holding Plate for Rivet			
1225	PLM04109	Passing Plate			
1226	PLM04111	Flat Plate			
1227	PLM04112	Arignment Plate			
1228	PLM04114	Scraper			
1229	PLM04116	Stopper Plate			
1230	PLM04117	Rail Bracket Right			
1231	PLM04118	Rail Bracket Left			
1232	PLM04119	Rivet Holding Plate			
1233	PLM09101#01	Magnet Sensor(with Harness)			
1234	PLM09101#02	Exit Sensor(with Harness)			
1235	PLM09101#04	Lid Detection Sensor(with Harness)			
1236	PLM09101#06	Power Switch (with Harness)			
1237	PLM09101#08	Front Sensor(with Harness)			
1238	PLM09101#14	Escaper Motor(with Harness)			
1239	PLM09101#18	Count Reset Switch (with Harness)			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z: Screw feeder model to be installed
1240	PLM09107#01	Magnet Sensor(with Harness)			
1241	PLM09107#02	Front Sensor(with Harness)			
1242	PLM09107#04	Lid Detection Sensor(with Harness)			
1243	PLM09107#14	Power Switch(with Harness)			
1244	PLM09107#16	Front Sensor LED(with Harness)			
1245	PLM09109#14	Power Switch (with Harness)			
1246	PLM09111#01	Lid Detection Sensor(with Harness)			
1247	PLM09111#09	Rotary Solenoid(with Harness)			
1248	PLM09111#15	Start Switch(with Harness)			
1249	PLMB0008#04	Escaper Unit:LV M3.0			
1250	PLMB0008#05	Escaper Unit:LV M3.5			
1251	PLMB0008#06	Escaper Unit:LV M4.0			
1252	PLMB0008#07	Escaper Unit:LV M5.0			
1253	PLMB0008#08	Escaper Unit:LV M6.0			
1254	PLMB0008#09	Escaper Unit:LV M8.0			
1255	PLMB0011#01	Rail Unit(for L*50) M2.0			
1256	PLMB0011#02	Rail Unit(for L*50) M2.3			
1257	PLMB0011#03	Rail Unit(for L*50) M2.6			
1258	PLMB0011#04	Rail Unit(for L*50) M3.0			
1259	PLMB0011#05	Rail Unit(for L*50) M3.5			
1260	PLMB0011#06	Rail Unit(for L*50) M4.0			
1261	PLMB0011#07	Rail Unit(for L*50) M5.0			
1262	PLMB0011#08	Rail Unit(for L*50) M6.0			
1263	PLMB0011#09	Rail Unit(for L*50) M8.0			
1264	PLMB0027	Escaper Base Unit			
1265	PLMB0027+PLM00614	Escaper Base Unit:Spec S			
1266	PLMB0028#04	Escaper Drive Unit:LV M3.0			
1267	PLMB0028#05	Escaper Drive Unit:LV M3.5			
1268	PLMB0028#06	Escaper Drive Unit:LV M4.0			
1269	PLMB0028#07	Escaper Drive Unit:LV M5.0			
1270	PLMB0028#08	Escaper Drive Unit:LV M6.0			
1271	PLMB0028#09	Escaper Drive Unit:LV M8.0			
1272	PLMB0029	Escaper Sensor Unit			
1273	PLMB0030#04	Escaper Assy:LV M3.0			
1274	PLMB0030#05	Escaper Assy:LV M3.5			
1275	PLMB0030#06	Escaper Assy:LV M4.0			
1276	PLMB0030#07	Escaper Assy:LV M5.0			
1277	PLMB0030#08	Escaper Assy:LV M6.0			
1278	PLMB0030#09	Escaper Assy:LV M8.0			
1279	PLMB0033	Brush Assy			
1280	PLMB0035	Magnet Drive			
1281	PLMB0038#02	Passing Plate Assy M3.0			
1282	PLMB0038#03	Passing Plate Assy M3.5 M4.0			
1283	PLMB0038#04	Passing Plate Assy M5.0 M6.0			
1284	PLMB0038#05	Passing Plate Assy M8.0			
1285	PLMB0039	Twin Magnet Drive			
1286	PLMB0041	Counter Assy:LV			
1287	PLMB0057#01	Escaper Assy:LS M2.0			
1288	PLMB0057#02	Escaper Assy:LS M2.3			
1289	PLMB0057#03	Escaper Assy:LS M2.6			
1290	PLMB0057#04	Escaper Assy:LS M3.0			
1291	PLMB0057#05	Escaper Assy:LS M3.5			
1292	PLMB0057#06	Escaper Assy:LS M4.0			
1293	PLMB0057#07	Escaper Assy:LS M5.0			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1294	PLMB0057#08	Escaper Assy:LS M6.0			
1295	PLMB0057#09	Escaper Assy:LS M8.0			
1296	PLMB0059	Counter Assy:LS			
1297	PLMB0071#04	Escaper Unit:LS-HR M3.0			
1298	PLMB0071#05	Escaper Unit:LS-HR M3.5			
1299	PLMB0071#06	Escaper Unit:LS-HR M4.0			
1300	PLMB0071#07	Escaper Unit:LS-HR M5.0			
1301	PLMB0071#08	Escaper Unit:LS-HR M6.0			
1302	PLMB0071#09	Escaper Unit:LS-HR M8.0			
1303	PLMB0072	Escaper Base Unit			
1304	PLMB0073#04	Escaper Drive Unit for R M3.0			
1305	PLMB0073#05	Escaper Drive Unit for R M3.5			
1306	PLMB0073#06	Escaper Drive Unit for R M4.0			
1307	PLMB0073#07	Escaper Drive Unit for R M5.0			
1308	PLMB0073#08	Escaper Drive Unit for R M6.0			
1309	PLMB0073#09	Escaper Drive Unit for R M8.0			
1310	PLMB0081#04	Escaper Unit:LS-HM M3.0			
1311	PLMB0081#05	Escaper Unit:LS-HM M3.5			
1312	PLMB0081#06	Escaper Unit:LS-HM M4.0			
1313	PLMB0081#07	Escaper Unit:LS-HM M5.0			
1314	PLMB0081#08	Escaper Unit:LS-HM M6.0			
1315	PLMB0081#09	Escaper Unit:LS-HM M8.0			
1316	PLMB0082#04	Escaper Drive Unit for M M3.0			
1317	PLMB0082#05	Escaper Drive Unit for M M3.5			
1318	PLMB0082#06	Escaper Drive Unit for M M4.0			
1319	PLMB0082#07	Escaper Drive Unit for M M5.0			
1320	PLMB0082#08	Escaper Drive Unit for M M6.0			
1321	PLMB0082#09	Escaper Drive Unit for M M8.0			
1322	PLMB0084	Bit Guide Assy			
1323	PLMB0205#04	Rail Unit(for L*25) M3.0			
1324	PLMB0205#05	Rail Unit(for L*25) M3.5			
1325	PLMB0205#06	Rail Unit(for L*25) M4.0			
1326	PLMB0205#07	Rail Unit(for L*25) M5.0			
1327	PLMB0205#08	Rail Unit(for L*25) M6.0			
1328	PLMB0205#09	Rail Unit(for L*25) M8.0			
1329	PLMB0301	LV Slider Base Unit			
1330	PLMB0302	LV Slider Unit			
1331	PLMB0401	LF Ejection Unit			
1332	PLMB0404#01	Escaper Unit:LF M2.0			
1333	PLMB0404#02	Escaper Unit:LF M2.3			
1334	PLMB0404#03	Escaper Unit:LF M2.6			
1335	PLMB0404#04	Escaper Unit:LF M3.0			
1336	PLMB0406	Brush Assy			
1337	PLMB0409#01	Escaper Drive Unit:LF M2.0			
1338	PLMB0409#02	Escaper Drive Unit:LF M2.3			
1339	PLMB0409#03	Escaper Drive Unit:LF M2.6			
1340	PLMB0409#04	Escaper Drive Unit:LF M3.0			
1341	PLMB0411	Counter Assy:LF			
1342	R20SET	Exchange Kit M2.0			
1343	R23SET	Exchange Kit M2.3			
1344	R26SET	Exchange Kit M2.6			
1345	R30SET	Exchange Kit M3.0			
1346	R35SET	Exchange Kit M3.5			
1347	R40SET	Exchange Kit M4.0			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1348	R50SET	Exchange Kit M5.0			
1349	RI10SET	Exchange Kit M1.0			
1350	RI10SET2	Exchange Kit M1.0			
1351	RI12SET	Exchange Kit M1.2			
1352	RI12SET2	Exchange Kit M1.2			
1353	RI14SET	Exchange Kit M1.4			
1354	RI14SET2	Exchange Kit M1.4			
1355	RI17SET	Exchange Kit M1.7			
1356	RI17SET2	Exchange Kit M1.7			
1357	RI20SET	Exchange Kit M2.0			
1358	RI20SET2	Exchange Kit M2.0			
1359	RI23SET	Exchange Kit M2.3			
1360	RI23SET2	Exchange Kit M2.3			
1361	RI26SET	Exchange Kit M2.6			
1362	RI26SET2	Exchange Kit M2.6			
1363	RI30SET	Exchange Kit M3.0			
1364	RI30SET2	Exchange Kit M3.0			
1365	RL20SET	Exchange Kit M2.0			
1366	RL23SET	Exchange Kit M2.3			
1367	RL26SET	Exchange Kit M2.6			
1368	RL30SET	Exchange Kit M3.0			
1369	RL35SET	Exchange Kit M3.5			
1370	RL40SET	Exchange Kit M4.0			
1371	RL50SET	Exchange Kit M5.0			
1372	RR20SET	Exchange Kit M2.0			
1373	RR23SET	Exchange Kit M2.3			
1374	RR26SET	Exchange Kit M2.6			
1375	RR30SET	Exchange Kit M3.0			
1376	RR35SET	Exchange Kit M3.5			
1377	RR40SET	Exchange Kit M4.0			
1378	RR50SET	Exchange Kit M5.0			
1379	RRL20SET	Exchange Kit M2.0			
1380	RRL23SET	Exchange Kit M2.3			
1381	RRL26SET	Exchange Kit M2.6			
1382	RRL30SET	Exchange Kit M3.0			
1383	RRL35SET	Exchange Kit M3.5			
1384	RRL40SET	Exchange Kit M4.0			
1385	RRL50SET	Exchange Kit M5.0			
1386	RTF-5010	LED Bezel			
1387	SC3W-M3-4	Speed Controller			
1388	SC3W-M3-4-I	Speed Controller			
1389	SCL2-08-H66	Speed Controller			
1390	SIM10SET	Exchange Kit M1.0			
1391	SIM12SET	Exchange Kit M1.2			
1392	SIM14SET	Exchange Kit M1.4			
1393	SIM17SET	Exchange Kit M1.7			
1394	SIM20SET	Exchange Kit M2.0			
1395	SIM23SET	Exchange Kit M2.3			
1396	SIM26SET	Exchange Kit M2.6			
1397	SIM30SET	Exchange Kit M3.0			
1398	SIR10SET	Exchange Kit M1.0			
1399	SIR12SET	Exchange Kit M1.2			
1400	SIR14SET	Exchange Kit M1.4			
1401	SIR17SET	Exchange Kit M1.7			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1402	SIR20SET	Exchange Kit M2.0			
1403	SIR23SET	Exchange Kit M2.3			
1404	SIR26SET	Exchange Kit M2.6			
1405	SIR30SET	Exchange Kit M3.0			
1406	SK-156	Rubber Foot			
1407	SR10SET	Exchange Kit M1.0			
1408	SR12SET	Exchange Kit M1.2			
1409	SR14SET	Exchange Kit M1.4			
1410	SR17SET	Exchange Kit M1.7			
1411	SR20SET	Exchange Kit M2.0			
1412	SR23SET	Exchange Kit M2.3			
1413	SR26SET	Exchange Kit M2.6			
1414	SR30SET	Exchange Kit M3.0			
1415	SRR10SET	Exchange Kit M1.0			
1416	SRR12SET	Exchange Kit M1.2			
1417	SRR14SET	Exchange Kit M1.4			
1418	SRR17SET	Exchange Kit M1.7			
1419	SRR20SET	Exchange Kit M2.0			
1420	SRR23SET	Exchange Kit M2.3			
1421	SRR26SET	Exchange Kit M2.6			
1422	SRR30SET	Exchange Kit M3.0			
1423	SSI02002	Right Cover			
1424	SSI02003	Left Cover			
1425	SSI02011	Base weight			
1426	SSI02012	Spacer			
1427	SSI02016	Escapar Unit Fixing Plate			
1428	SSI03001#01	Escaper M1.0:SSIE10			
1429	SSI03001#02	Escaper M1.2:SSIE12			
1430	SSI03001#03	Escaper M1.4:SSIE14			
1431	SSI03001#04	Escaper M1.7:SSIE17			
1432	SSI03001#05	Escaper M2.0:SSIE20			
1433	SSI03001#06	Escaper M2.3:SSIE23			
1434	SSI03001#07	Escaper M2.6:SSIE26			
1435	SSI03001#08	Escaper M3.0:SSIE30			
1436	SSI03003#01	Guide Right M1.0:SSIEM10			
1437	SSI03003#02	Guide Right M1.2:SSIEM12			
1438	SSI03003#03	Guide Right M1.4:SSIEM14			
1439	SSI03003#04	Guide Right M1.7:SSIEM17			
1440	SSI03003#05	Guide Right M2.0:SSIEM20			
1441	SSI03003#06	Guide Right M2.3:SSIEM23			
1442	SSI03003#07	Guide Right M2.6:SSIEM26			
1443	SSI03003#08	Guide Right M3.0:SSIEM30			
1444	SSI03004	Escaper Guide 10-17 (M1.0-M1.7:SSIER10-17)			
1445	SSI03005	Escaper Guide 20-30 (M2.0-M3.0:SSIER20-30)			
1446	SSI09002#03	Front Sensor Detector LED (With Harness)			
1447	SSI09002#05	Power Switch (With Harness)			
1448	SSI09002#07	Power Plug (With Harness)			
1449	SSI09002#14	Front Sensor (With Harness)			
1450	SSI09002#19	Signal Harness			
1451	SSI09003#02	Sensor Junction Cable-Origin Sensor			
1452	SSI09003#04	LED Junction Cable			
1453	SSI09003#06	Switch Junction Cable			
1454	SSI09003#08	Signal Junction Cable			
1455	SSI09003#09	Motor Junction Cable			
1456	SSI09003#11	Power Junction Cable			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1457	SSI09003#12	Jumper Connector			
1458	SSI09003#15	Sensor Junction Cable-Front Sensor			
1459	SSI09003#16	Solenoid Junction Cable			
1460	SSI10001#01	Escaper Guide Left:M10			
1461	SSI10001#02	Escaper Guide Left:M12			
1462	SSI10001#03	Escaper Guide Left:M14			
1463	SSI10001#04	Escaper Guide Left:M17			
1464	SSI10001#05	Escaper Guide Left:M20			
1465	SSI10001#06	Escaper Guide Left:M23			
1466	SSI10001#07	Escaper Guide Left:M26			
1467	SSI10001#08	Escaper Guide Left:M30			
1468	SSI10004#01	Stopper Assy M1.0:SSIES10			
1469	SSI10004#02	Stopper Assy M1.2:SSIES12			
1470	SSI10004#03	Stopper Assy M1.4:SSIES14			
1471	SSI10004#04	Stopper Assy M1.7:SSIES17			
1472	SSI10004#05	Stopper Assy M2.0:SSIES20			
1473	SSI10004#06	Stopper Assy M2.3:SSIES23			
1474	SSI10004#07	Stopper Assy M2.6:SSIES26			
1475	SSI10004#08	Stopper Assy M3.0:SSIES30			
1476	SSI10007	Stopper(t0.6)			
1477	SSI10018	Solenoid Unit:SSI			
1478	SSI10024	Front Sensor Unit:SSI			
1479	SSI10027	Bit Guide Unit:SSI			
1480	SSI10029	Cover Assy:Hopper Front			
1481	SSI10033	Driving Gear Unit:SSI			
1482	SSI10035#01	Front Cover Assy (With Sticker)			
1483	SSI10035#02	Front Cover Assy (With Sticker)			
1484	SSI10038	Cover Assy:SSI (With Sticker)			
1485	SSI10039	Rear Cover Assy			
1486	SSI10040	Board bracket Assy			
1487	SSI10055#01	Escaper Driving Unit 2:SSI-R (12)			
1488	SSI10055#02	Escaper Driving Unit 2:SSI-R (23)			
1489	SSI10056#01	Escaper Driving Unit 2:SSI-M (12)			
1490	SSI10056#02	Escaper Driving Unit 2:SSI-M (23)			
1491	SSI10057#01	Escaper Unit 2:SSI-R10 M1.0			
1492	SSI10057#02	Escaper Unit 2:SSI-R12 M1.2			
1493	SSI10057#03	Escaper Unit 2:SSI-R14 M1.4			
1494	SSI10057#04	Escaper Unit 2:SSI-R17 M1.7			
1495	SSI10057#05	Escaper Unit 2:SSI-R20 M2.0			
1496	SSI10057#06	Escaper Unit 2:SSI-R23 M2.3			
1497	SSI10057#07	Escaper Unit 2:SSI-R26 M2.6			
1498	SSI10057#08	Escaper Unit 2:SSI-R30 M3.0			
1499	SSI10058#01	Escaper Unit 2:SSI-M10 M1.0			
1500	SSI10058#02	Escaper Unit 2:SSI-M12 M1.2			
1501	SSI10058#03	Escaper Unit 2:SSI-M14 M1.4			
1502	SSI10058#04	Escaper Unit 2:SSI-M17 M1.7			
1503	SSI10058#05	Escaper Unit 2:SSI-M20 M2.0			
1504	SSI10058#06	Escaper Unit 2:SSI-M23 M2.3			
1505	SSI10058#07	Escaper Unit 2:SSI-M26 M2.6			
1506	SSI10058#08	Escaper Unit 2:SSI-M30 M3.0			
1507	SSIMMA01	Operation Manual SSI-M Series			
1508	SSIRMA01	Operation Manual SSI-R Series			
1509	TBS01034	Screw Guide			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1510	TEK30410	Brush Driving Gear			
1511	TEK51001	Bit Guide			
1512	TEK51020	Passing Plate			
1513	TEK81011	Drive Belt(φ5-285)			
1514	TFM00054	Screw Guide			
1515	TFM00114	Right Side Cover			
1516	TFM00116	Left Side Cover			
1517	TH-TM-112	Hinge			
1518	TH-TM-19	Hinge			
1519	TK-15	Rubber Foot			
1520	TKA09054	Sub Circuit Board			
1521	TL-233-2	Grip Screw			
1522	TM-166-12	Bumper			
1523	TM-166-18	Bumper			
1524	TM-166-3	Bumper			
1525	TM-166-8	Bumper			
1526	TM-180-302	Bumper (NJ-80F)			
1527	TM-182-816-10	Urethane Roll Stock			
1528	TM-KG-74	Grommet			
1529	TNP00010	Y Shaft			
1530	TNP00018	Z Shaft			
1531	TNP00031#01	Shutter Plate φ8.0			
1532	TNP00031#02	Shutter Plate φ7.5			
1533	TNP00031#03	Shutter Plate φ7.0			
1534	TNP00031#04	Shutter Plate φ6.5			
1535	TNP00031#05	Shutter Plate φ6.0			
1536	TNP00031#06	Shutter Plate φ5.5			
1537	TNP00031#07	Shutter Plate φ5.0			
1538	TNP00031#08	Shutter Plate φ4.5			
1539	TNP00031#09	Shutter Plate φ4.0			
1540	TNP00031#10	Shutter Plate φ3.5			
1541	TNP00031#11	Shutter Plate φ3.0			
1542	TNP00031#12	Shutter Plate φ2.3			
1543	TNP00031#13	Shutter Plate φ1.8			
1544	TNP00031**	Shutter Plate			
1545	TNP00032	Shutter Stopper			
1546	TNP00039	Connecting Bracket			
1547	TNP00044	Side Cover Left			
1548	TNP00061	Holding Plate Bracket			
1549	TNP00066	Escaper Guide M20-30			
1550	TNP00067	Escaper Guide M10-17			
1551	TNP00080	Holding Plate			
1552	TNP00082#**	Mouth			
1553	TNP00082#01	Mouth φ8.0			
1554	TNP00082#02	Mouth φ7.5			
1555	TNP00082#03	Mouth φ7.0			
1556	TNP00082#04	Mouth φ6.5			
1557	TNP00082#05	Mouth φ6.0			
1558	TNP00082#06	Mouth φ5.5			
1559	TNP00082#07	Mouth φ5.0			
1560	TNP00082#08	Mouth φ4.5			
1561	TNP00082#09	Mouth φ4.0			
1562	TNP00082#10	Mouth φ3.5			
1563	TNP00082#11	Mouth φ3.0			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z: Screw feeder model to be installed
1564	TNP00082#12	Mouth φ2.3			
1565	TNP00082#13	Mouth φ1.8			
1566	TNP09430#07	Origin Sensor (With Harness)			
1567	TNP09430#08	INPORT Harness			
1568	TNP09430#09	EXPORT Harness			
1569	TNP09430#10	Screw Out Sensor (With Harness)			
1570	TNP09430#13	Sensor Harness 1(CLOSE)			
1571	TNP09430#14	Sensor Harness 2(OPEN)			
1572	TNP09430#17	PULL Valve Harness			
1573	TNP09430#18	Shutter Valve Harness			
1574	TNP09430#19	PUSH Valve Harness			
1575	TNP09430#20	Main Motor (With Harness)			
1576	TNP09430#21	Signal relay cable			
1577	TNP09430#22	Stepping Motor 2 (With Harness)			
1578	TNP09430#28	Front Sensor (With Harness)			
1579	TNP09430#30	Harness30 (With Knob)			
1580	TNP09430#32	Power Plug (With Harness)			
1581	TNP09431#11	LED4 Harness			
1582	TNP09431#14	LED1 Harness			
1583	TNP09431#15	LED2 Harness			
1584	TNP09431#16	LED3 Harness			
1585	TNP09431#31	Power Swich (With Harness)			
1586	TNPB0002	Block "C" Assy			
1587	TNPB0002	Block "D" Assy			
1588	TNPB0003	Block "B" Assy			
1589	TNPB0100	Base Assy			
1590	TNPB0102	Valve Unit			
1591	TNPB0200#**	PP Unit			
1592	TNPB0200#01	PP Unit φ8.0			
1593	TNPB0200#02	PP Unit φ7.5			
1594	TNPB0200#03	PP Unit φ7.0			
1595	TNPB0200#04	PP Unit φ6.5			
1596	TNPB0200#05	PP Unit φ6.0			
1597	TNPB0200#06	PP Unit φ5.5			
1598	TNPB0200#07	PP Unit φ5.0			
1599	TNPB0200#08	PP Unit φ4.5			
1600	TNPB0200#09	PP Unit φ4.0			
1601	TNPB0200#10	PP Unit φ3.5			
1602	TNPB0200#11	PP Unit φ3.0			
1603	TNPB0200#12	PP Unit φ2.3			
1604	TNPB0200#13	PP Unit φ1.8			
1605	TNPB0213#**	PP ARM Assy			
1606	TNPB0213#01	PP ARM Assy φ8.0			
1607	TNPB0213#02	PP ARM Assy φ7.5			
1608	TNPB0213#03	PP ARM Assy φ7.0			
1609	TNPB0213#04	PP ARM Assy φ6.5			
1610	TNPB0213#05	PP ARM Assy φ6.0			
1611	TNPB0213#06	PP ARM Assy φ5.5			
1612	TNPB0213#07	PP ARM Assy φ5.0			
1613	TNPB0213#08	PP ARM Assy φ4.5			
1614	TNPB0213#09	PP ARM Assy φ4.0			
1615	TNPB0213#10	PP ARM Assy φ3.5			
1616	TNPB0213#11	PP ARM Assy φ3.0			
1617	TNPB0213#12	PP ARM Assy φ2.3			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1618	TNPB0213#13	PP ARM Assy φ1.8			
1619	TNPB0214	Y-BASE Assy			
1620	TNPB0300#**	Shutter Assy			
1621	TNPB0300#01	Shutter Assy φ8.0			
1622	TNPB0300#02	Shutter Assy φ7.5			
1623	TNPB0300#03	Shutter Assy φ7.0			
1624	TNPB0300#04	Shutter Assy φ6.5			
1625	TNPB0300#05	Shutter Assy φ6.0			
1626	TNPB0300#06	Shutter Assy φ5.5			
1627	TNPB0300#07	Shutter Assy φ5.0			
1628	TNPB0300#08	Shutter Assy φ4.5			
1629	TNPB0300#09	Shutter Assy φ4.0			
1630	TNPB0300#10	Shutter Assy φ3.5			
1631	TNPB0300#11	Shutter Assy φ3.0			
1632	TNPB0300#12	Shutter Assy φ2.3			
1633	TNPB0300#13	Shutter Assy φ1.8			
1634	TNPB0402	DC Jack Assy			
1635	TNPB0601	Front Cover Assy			
1636	TNPB0602	Rear Cover Assy			
1637	TNPB0603	Side Cover Right Assy			
1638	TOKX0383	Brush Assy			
1639	TPO00407	Magnetic Arm Spring			
1640	TPO00409	Stainless Spacer			
1641	TPO00461	Separating Rail			
1642	TPO00508	Roller Arm: Press-fit			
1643	TPO00509	Driving Pulley			
1644	TPO00512	E-Stopper			
1645	TPO00604#01	Escaper:M1.0 SIE10			
1646	TPO00604#02	Escaper:M1.2 SIE12			
1647	TPO00604#03	Escaper:M1.4 SIE14			
1648	TPO00604#04	Escaper:M1.7 SIE17			
1649	TPO00604#05	Escaper:M2.0 SIE20			
1650	TPO00604#06	Escaper:M2.3 SIE23			
1651	TPO00604#07	Escaper:M2.6 SIE26			
1652	TPO00604#08	Escaper:M3.0 SIE30			
1653	TPO00604#09	Escaper:M3.5 SIE35			
1654	TPO00604#10	Escaper:M4.0 SIE40			
1655	TPO00604#11	Escaper:M5.0 SIE50			
1656	TPO00604#12	Escaper:M6.0 SIE60			
1657	TPO00608#01	Escaper Guide Right M1.0:SIEM10			
1658	TPO00608#02	Escaper Guide Right M1.2:SIEM12			
1659	TPO00608#03	Escaper Guide Right M1.4:SIEM14			
1660	TPO00608#04	Escaper Guide Right M1.7:SIEM17			
1661	TPO00608#05	Escaper Guide Right M2.0:SIEM20			
1662	TPO00608#06	Escaper Guide Right M2.3:SIEM23			
1663	TPO00608#07	Escaper Guide Right M2.6:SIEM26			
1664	TPO00608#08	Escaper Guide Right M3.0:SIEM30			
1665	TPO00608#09	Escaper Guide Right M3.5:SIEM35			
1666	TPO00608#10	Escaper Guide Right M4.0:SIEM40			
1667	TPO00608#11	Escaper Guide Right M5.0:SIEM50			
1668	TPO00608#12	Escaper Guide Right M6.0:SIEM60			
1669	TPO00610#01	Escaper Guide for Robot M1.0-1.7:SIER10-17			
1670	TPO00610#02	Escaper Guide for Robot M2.0-3.0:SIER20-30			
1671	TPO00610#03	Escaper Guide for Robot M3.5-4.0:SIER35-40			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1672	TPO00610#04	Escaper Guide for Robot M5.0-6.0:SIER50-60			
1673	TPO00618	Escaper Driving Unit(M)			
1674	TPO00619	Escaper Driving Unit(R)			
1675	TPO00620#01	Escaper Unit:OM-26M M2.0			
1676	TPO00620#02	Escaper Unit:OM-26M M2.3			
1677	TPO00620#03	Escaper Unit:OM-26M M2.6			
1678	TPO00620#04	Escaper Unit:OM-26M M3.0			
1679	TPO00620#05	Escaper Unit:OM-26M M3.5			
1680	TPO00620#06	Escaper Unit:OM-26M M4.0			
1681	TPO00620#07	Escaper Unit:OM-26M M5.0			
1682	TPO00620#08	Escaper Unit:OM-26M M6.0			
1683	TPO00621#01	Escaper Unit:OM-26R M2.0			
1684	TPO00621#02	Escaper Unit:OM-26R M2.3			
1685	TPO00621#03	Escaper Unit:OM-26R M2.6			
1686	TPO00621#04	Escaper Unit:OM-26R M3.0			
1687	TPO00621#05	Escaper Unit:OM-26R M3.5			
1688	TPO00621#06	Escaper Unit:OM-26R M4.0			
1689	TPO00621#07	Escaper Unit:OM-26R M5.0			
1690	TPO00621#08	Escaper Unit:OM-26R M6.0			
1691	TPO00622	Front Sensor Unit			
1692	TPO00701	Right Wall 5			
1693	TPO00708	Presser Plate #2			
1694	TPO00711	Upper Lid			
1695	TPO00808	Extention Spring			
1696	TPO00809	Compression Spring			
1697	TPO00904	Fixing Bolt			
1698	TPO00905	Bit Guide Assy: OM-26M			
1699	TPO00906	Front Cover Assy			
1700	TPO00907	Front Cover Assy			
1701	TPO00908	Brush Assy			
1702	TPO00913	Bit Guide Unit			
1703	TPO00914	Bit Guide Attaching Unit			
1704	TPO01002#03	Front Sensor Detector LED (With Harness)			
1705	TPO01002#05	Power Switch (With Harness)			
1706	TPO01002#06	Power Plug (With Harness)			
1707	TPO01002#13	Front Sensor (With Harness)			
1708	TPO01002#17	Main Motor (With Harness)			
1709	TPO01002#18	Signal Harness			
1710	TPO01003#02	Sensor Junction Cable-Origin Sensor			
1711	TPO01003#04	LED Junction Cable			
1712	TPO01003#07	Signal Junction Cable			
1713	TPO01003#08	Motor Junction Cable			
1714	TPO01003#10	Power Junction Cable			
1715	TPO01003#11	Jumper Connector			
1716	TPO01003#14	Sensor Junction Cable-Front Sensor			
1717	TPO01003#15	Solenoid Junction Cable			
1718	TPO11011#01	Passing Plate:OM20-30 M2.0-3.0			
1719	TPO11011#02	Passing Plate:OM35-40 M3.5-4.0			
1720	TPO11011#03	Passing Plate:OM50 M5.0			
1721	TPO11011#04	Passing Plate:OM60 M6.0			
1722	TPO11031	Motor Bracket Unit			
1723	TPO11032	Magnet Arm Unit			
1724	TPO11033	Solenoid Unit			
1725	TPO11034	Escaper Fixing Unit			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1726	TPO11035	Presser Plate Unit			
1727	TPO11039	Brush Shaft Assy			
1728	TPO11040	Motor Bracket (With Shaft)			
1729	TPO11048	Front Bottom Cover Assy (With Sticker)			
1730	TPO11049	Outside Cover Assy			
1731	TPO11203	Motor Bracket Unit (B)			
1732	TPO11208	Outside Cover Assy (B)			
1733	TPO11210	Front Bottom Cover Assy (B) (With Sticker)			
1734	TPO11211	Escaper Fixing Unit (B)			
1735	TPO11301	Right Wall 2			
1736	TPO11302	Bottom Plate			
1737	TPO11310	Scraper Left (t1.0)			
1738	TPO19008	B Motor Junction Cable			
1739	TPO20803	E-Stopper Spring Holding Assy			
1740	TPO20804	E-Stopper Spring Stopping Screw Assy			
1741	TPO20806#01	Stopper Assy M1.0:SIES10			
1742	TPO20806#02	Stopper Assy M1.2:SIES12			
1743	TPO20806#03	Stopper Assy M1.4:SIES14			
1744	TPO20806#04	Stopper Assy M1.7:SIES17			
1745	TPO20806#05	Stopper Assy M2.0:SIES20			
1746	TPO20806#06	Stopper Assy M2.3:SIES23			
1747	TPO20806#07	Stopper Assy M2.6:SIES26			
1748	TPO20806#08	Stopper Assy M3.0:SIES30			
1749	TPO20806#09	Stopper Assy M3.5:SIES35			
1750	TPO20806#10	Stopper Assy M4.0:SIES40			
1751	TPO20806#11	Stopper Assy M5.0:SIES50			
1752	TPO20806#12	Stopper Assy M6.0:SIES60			
1753	TPO20812#01	Escaper Guide Left(With Flange):M1.0			
1754	TPO20812#02	Escaper Guide Left(With Flange):M1.2			
1755	TPO20812#03	Escaper Guide Left(With Flange):M1.4			
1756	TPO20812#04	Escaper Guide Left(With Flange):M1.7			
1757	TPO20812#05	Escaper Guide Left(With Flange):M2.0			
1758	TPO20812#06	Escaper Guide Left(With Flange):M2.3			
1759	TPO20812#07	Escaper Guide Left(With Flange):M2.6			
1760	TPO20812#08	Escaper Guide Left(With Flange):M3.0			
1761	TPO20812#09	Escaper Guide Left(With Flange):M3.5			
1762	TPO20812#10	Escaper Guide Left(With Flange):M4.0			
1763	TPO20812#11	Escaper Guide Left(With Flange):M5.0			
1764	TPO20812#12	Escaper Guide Left(With Flange):M6.0			
1765	TPO21202	Ground Wire			
1766	TPO40615#01	Escaper Guide 2 for Robot:M1.0-1.7 SIE2R10-17			
1767	TPO40615#02	Escaper Guide 2 for Robot:M2.0-3.0 SIE2R20-30			
1768	TPO40615#03	Escaper Guide 2 for Robot:M3.5-4.0 SIE2R35-40			
1769	TPO40615#04	Escaper Guide 2 for Robot:M5.0-6.0 SIE2R50-60			
1770	TPO40620#01	Escaper Unit:OM2-26M M2.0			
1771	TPO40620#02	Escaper Unit:OM2-26M M2.3			
1772	TPO40620#03	Escaper Unit:OM2-26M M2.6			
1773	TPO40620#04	Escaper Unit:OM2-26M M3.0			
1774	TPO40620#05	Escaper Unit:OM2-26M M3.5			
1775	TPO40620#06	Escaper Unit:OM2-26M M4.0			
1776	TPO40620#07	Escaper Unit:OM2-26M M5.0			
1777	TPO40620#08	Escaper Unit:OM2-26M M6.0			
1778	TPO40621#01	Escaper Unit:OM2-26R M2.0			
1779	TPO40621#02	Escaper Unit:OM2-26R M2.3			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z: Screw feeder model to be installed
1780	TPO40621#03	Escaper Unit:OM2-26R M2.6			
1781	TPO40621#04	Escaper Unit:OM2-26R M3.0			
1782	TPO40621#05	Escaper Unit:OM2-26R M3.5			
1783	TPO40621#06	Escaper Unit:OM2-26R M4.0			
1784	TPO40621#07	Escaper Unit:OM2-26R M5.0			
1785	TPO40621#08	Escaper Unit:OM2-26R M6.0			
1786	TPO40622	Escaper Driving Unit:OM2-26M			
1787	TPO40623	Escaper Driving Unit:OM2-26R			
1788	TPO40631#01	Escaper Unit:OM-26R(Model Mix ver) M2.0			
1789	TPO40631#02	Escaper Unit:OM-26R(Model Mix ver) M2.3			
1790	TPO40631#03	Escaper Unit:OM-26R(Model Mix ver) M2.6			
1791	TPO40631#04	Escaper Unit:OM-26R(Model Mix ver) M3.0			
1792	TPO40631#05	Escaper Unit:OM-26R(Model Mix ver) M3.5			
1793	TPO40631#06	Escaper Unit:OM-26R(Model Mix ver) M4.0			
1794	TPO40631#07	Escaper Unit:OM-26R(Model Mix ver) M5.0			
1795	TPO40631#08	Escaper Unit:OM-26R(Model Mix ver) M6.0			
1796	TPO40633	Escaper Driving Unit:OM-26R(Model Mix ver)			
1797	TPO90982	Roller: Brush Driving Shaft			
1798	TPO90988	Brush Bracket			
1799	TPO90989	Brush Holding Plate			
1800	TPO90990	Brush			
1801	TPO91101	E-Stopper Spring			
1802	TPO91202	Scraper Right			
1803	UI315-15(CCC)	UI315-15 AC Adapter DC15V with CCC Cord			
1804	UI315-15(KC)	UI315-15 AC Adapter DC15V with KC Cord			
1805	UIA345-2419(KC)	UIA345-2419 AC Adapter DC24V with KC Cord			
1806	UIB345-1530(PSE)	UIB345-1530 AC Adapter DC15V with PSE Cord			
1807	UNI315-1510(CE)	UNI315-1510 AC Adapter DC15V with CE Cord			
1808	UNI315-1510(PSE)	UNI315-1510 AC Adapter DC15V with PSE Cord			
1809	UNI315-1510(UL)	UNI315-1510 AC Adapter DC15V with UL Cord			
1810	UNI345-1530(CCC)	UNI345-1530 AC Adapter DC15V with CCC Cord			
1811	UNI345-1530(CE)	UNI345-1530 AC Adapter DC15V with CE Cord			
1812	UNI345-1530(UL)	UNI345-1530 AC Adapter DC15V with UL Cord			
1813	UNI345-2419(CCC)	UNI345-2419 AC Adapter DC24V with CCC Cord			
1814	UNI345-2419(CE)	UNI345-2419 AC Adapter DC24V with CE Cord			
1815	UNI345-2419(PSE)	UNI345-2419 AC Adapter DC24V with PSE Cord			
1816	UNI345-2419(UL)	UNI345-2419 AC Adapter DC24V with UL Cord			
1817	VSY-F-44M	Filter			
1818	VSY-L07-444S-F	Ejector			
1819	WR10	Exchange Kit M1.0			
1820	WR12	Exchange Kit M1.2			
1821	WR14	Exchange Kit M1.4			
1822	WR17	Exchange Kit M1.7			
1823	WR20	Exchange Kit M2.0			
1824	WR23	Exchange Kit M2.3			
1825	WR26	Exchange Kit M2.6			
1826	WR30	Exchange Kit M3.0			
1827	WR6-10	Compression Spring			
1828	WRENCH-M2.0	Allen Wrench			
1829	ZDE00001	Logo Sticker			
1830	ZDE00010#03	Sticker:NJ-23			
1831	ZDE00010#04	Sticker:NJ-45			
1832	ZDE00010#07	Sticker:NSB			
1833	ZDE00010#08	Sticker:NSBI			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1834	ZDE00010#09	Sticker:NSRI			
1835	ZDE00010#10	Sticker:NSR			
1836	ZDE00012#01	Sticker:NJL-23			
1837	ZDE00012#03	Sticker:NJL-45			
1838	ZPV00001#01	Main Circuit Board For NJ-NSB			
1839	ZPV00001#02	Main Circuit Board For NJR			
1840	ZPV00001#03	Main Circuit Board For NSR			
1841	ZPV00001#04	Main Circuit Board For NSRI-NSBI			
1842	ZPV00001#05	Main Circuit Board For OM			
1843	ZPV00001#06	Main Circuit Board For SSI			
1844	ZPV00001#07	Main Circuit Board For SS			
1845	ZPV00001#08	Main Circuit Board For FM-FME			
1846	ZPV00001#09	Main Circuit Board For NSRI-B			
1847	ZPV00001#10	Main Circuit Board For OM-26RB			
1848	ZPV00001#17	SPM Board For NSRI-NSBI			
1849	ZPV00001#18	SPM Board For OM			
1850	ZPV00001#19	SPM Board For SSI-M			
1851	ZPV00001#20	SPM Board For SSI-R			
1852	ZPV00001#21	SPM Board For NSRI-B			
1853	ZPV00001#22	SPM Board For OM-26RB			
1854	ZPV00002#05	Main Circuit Board For BS-CS			
1855	ZPV00002#06	Counter Board For BS-CS			
1856	ZPV00002#07	Main Circuit Board For BS-CL			
1857	ZPV00002#08	Counter Board For BS-CL			
1858	ZPV00002#09	Main Circuit Board For BS-S			
1859	ZPV00002#10	Main Circuit Board For BS-L			
1860	ZPV00002#11	PP Control Board For BS-P			
1861	ZPV00003#05	Main Circuit Board For NJ-80			
1862	ZPV00003#06	Main Circuit Board For T-510			
1863	ZPV00004#01	Main Circuit Board For LV-H(M5 or less)			
1864	ZPV00004#02	Main Circuit Board For LV-H(M6 and over)			
1865	ZPV00004#03	Main Circuit Board For LV-B(M5 or less)			
1866	ZPV00004#04	Main Circuit Board For LV-B(M6 and over)			
1867	ZPV00004#05	Main Circuit Board For LV-S(M5 or less)			
1868	ZPV00004#06	Main Circuit Board For LV-S(M6 and over)			
1869	ZPV00004#07	Main Circuit Board For LS-HM			
1870	ZPV00004#08	Main Circuit Board For LS-HR			
1871	ZPV00004#09	Main Circuit Board For LF			
1872	ZZM00021	Pan Head Screw PW,SW M2*10 (10pcs)			
1873	ZZM00027	Pan Head Screw PW,SW M2.6*4 (10pcs)			
1874	ZZM00028	Pan Head Screw PW,SW M2.6*5 (10pcs)			
1875	ZZM00029	Pan Head Screw PW,SW M2.6*6 (10pcs)			
1876	ZZM00030	Pan Head Screw PW,SW M2.6*8 (10pcs)			
1877	ZZM00032	Pan Head Screw PW,SW M2.6*12 (10pcs)			
1878	ZZM00033	Pan Head Screw PW,SW M2.6*14 (10pcs)			
1879	ZZM00034	Pan Head Screw PW,SW M2.6*16 (10pcs)			
1880	ZZM00038	Pan Head Screw PW,SW M3*6 (10pcs)			
1881	ZZM00054	Pan Head Screw PW,SW M2.6*5 Loosening Prevention (10pcs)			
1882	ZZM00055	Pan Head Screw PW,SW M2.6*8 Loosening Prevention (10pcs)			
1883	ZZM00057	Pan Head Screw PW(s),SW M2*5 (10pcs)			
1884	ZZM00060	Pan Head Screw PW(s),SW M2.6*5 (10pcs)			
1885	ZZM00061	Pan Head Screw PW(s),SW M2.6*8 (10pcs)			
1886	ZZM00062	Pan Head Screw PW(s),SW M3*6 (10pcs)			
1887	ZZM00063	Pan Head Screw PW(s),SW M3*8 (10pcs)			
1888	ZZM00067	Pan Head Screw PW,SW M2.6*5 Ni (10pcs)			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1889	ZZM00068	Pan Head Screw PW,SW M2.6*8 Ni (10pcs)			
1890	ZZM00071	Pan Head Screw PW(s),SW M2*8 Ni (10pcs)			
1891	ZZM00072	Pan Head Screw PW(s),SW M2.6*8 Ni (10pcs)			
1892	ZZM00074	Pan Head Screw SW M2.6*5 (10pcs)			
1893	ZZM00096	Plus Countersunk Head Screw M2*5 (10pcs)			
1894	ZZM00099	Plus Countersunk Head Screw M2.6*4 (10pcs)			
1895	ZZM00100	Plus Countersunk Head Screw M2.6*5 (10pcs)			
1896	ZZM00102	Plus Countersunk Head Screw M2.6*8 (10pcs)			
1897	ZZM00104	Plus Countersunk Head Screw M3*5 (10pcs)			
1898	ZZM00117	Plus Countersunk Head Screw M2.6*4 Ni (10pcs)			
1899	ZZM00120	Plus Countersunk Head Screw M2*4,Ni Plating,Looseness Prevention (10pcs)			
1900	ZZM00144	Plus Truss Head Screw M3*6 (10pcs)			
1901	ZZM00157	Plus Truss Head Screw M2*3 Ni (10pcs)			
1902	ZZM00159	Plus Truss Head Screw M2.6*3 Ni (10pcs)			
1903	ZZM00160	Plus Truss Head Screw M2.6*4 Ni (10pcs)			
1904	ZZM00161	Plus Truss Head Screw M2.6*5 Ni (10pcs)			
1905	ZZM00185	Hex. Socket Head Bolt M2.6*10 (10pcs)			
1906	ZZM00186	Hex. Socket Head Bolt M2.6*12 (10pcs)			
1907	ZZM00188	Hex. Socket Head Bolt M2.6*20 (10pcs)			
1908	ZZM00191	Hex.Socket Head Bolt M3*8 (10pcs)			
1909	ZZM00192	Hex. Socket Head Bolt M3*10 (10pcs)			
1910	ZZM00196	Hex. Socket Head Bolt M3*20 (10pcs)			
1911	ZZM00197	Hex. Socket Head Bolt M3*25 (10pcs)			
1912	ZZM00261	Hex. Socket Head Bolt PW,SW M2.6*5 (10pcs)			
1913	ZZM00262	Hex. Socket Head Bolt PW,SW M3*6 (10pcs)			
1914	ZZM00264	Hex. Socket Head Bolt PW,SW M3*10 (10pcs)			
1915	ZZM00265	Hex. Socket Head Bolt PW,SW M3*15 (10pcs)			
1916	ZZM00266	Hex. Socket Head Bolt PW,SW M4*8 (10pcs)			
1917	ZZM00267	Hex. Socket Head Bolt PW,SW M4*10 (10pcs)			
1918	ZZM00289	Hex. Socket Head Bolt PW,SW M2.6*8 (10pcs)			
1919	ZZM00292	Hex. Socket Head Bolt M2.5*8 Ni (10pcs)			
1920	ZZM00358	Binding Head Screw M2.6*14 (10pcs)			
1921	ZZM00360	Binding Head Screw M2*3 Ni (10pcs)			
1922	ZZM00361	Binding Head Screw SW M2*3 Ni (10pcs)			
1923	ZZM00363	Binding Head Tapping Screw M2.6*8 Ni (10pcs)			
1924	ZZM00388	Hex. Socket Head Screw M4*8 Loosening Prevention (10pcs)			
1925	ZZM00393	Plain Washer M2.6 (10pcs)			
1926	ZZM00394	Plain Washer M3 (10pcs)			
1927	ZZM00396	Plain Washer M5 (10pcs)			
1928	ZZM00397	Plain Washer M6 (10pcs)			
1929	ZZM00417	Spring Washer M2.6 (10pcs)			
1930	ZZM00418	Spring Washer M3 (10pcs)			
1931	ZZM00441	Toothed Lock Washer M2 Ni (10pcs)			
1932	ZZM00442	Toothed Lock Washer M2.6 Ni (10pcs)			
1933	ZZM00448	Hex. Nut M6 (10pcs)			
1934	ZZM00510	E-Type Snap Ring E-3 (10pcs)			
1935	ZZM00512	E-Type Snap Ring E-5 (10pcs)			
1936	ZZM00536	C-Type Snap Ring Nominal 6 (10pcs)			
1937	ZZM00556	Spring Pin 2*8 (10pcs)			
1938	ZZM00557	Spring Pin 2*16 (10pcs)			
1939	ZZM00558	Spring Pin 2.5*14 (10pcs)			
1940	ZZM00559	Spring Pin 2.5*16 (10pcs)			
1941	ZZM00560	Spring Pin 2.5*20 (10pcs)			

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1942	ZZM00564	Hex Metal Spacer (10pcs)			
1943	ZZM00573	Hex Metal Spacer Nut (10pcs)			
1944	ZZM00577	Hex Metal Spacer Nut			
1945	ZZM00584	Brass Spacer			
1946	ZZM00587	Stainless Spacer			
1947	ZZM00588	Stainless Spacer			
1948	ZZM00593	Stainless Spacer			
1949	ZZM00612	Hex. Socket Head Bolt M2.6*25 (10pcs)			
1950	ZZM00614	Plus Countersunk Head Screw M2.6*5,Nylok (10pcs)			
1951	ZZM00620	Pan Head Screw PW,SW M3*7 Loosening Prevention (10pcs)			
1952	ZZM00622	Pan Head Screw PW(s),SW M3*5 (10pcs)			
1953	ZZM00623	Plus Countersunk Head Screw M3*5 Ni (10pcs)			
1954	ZZM00628	Polyurethan Slider/STW-FT45/4.6X7.2X0.13 (10pcs)			
1955	ZZM00681	C-Type Snap Ring S-6 (10pcs)			
1956	ZZM00803	Pan Head Screw PW(s),SW M2.6*6 (10pcs)			
1957	ZZM00916	Hex. Socket Head Bolt PW,SW M3*14 (10pcs)			
1958	ZZM01008	Hex. Socket Head Bolt PW,SW M2.6*10 (10pcs)			
1959	ZZM01009	Hex. Socket Head Bolt PW,SW M2.6*12 (10pcs)			
1960	ZZM01079	Thin head screw M4 (10pcs)			
1961	ZZM01080	Coil Bushing 2.6*2			
1962	ZZM01081	Weld Bolt BT4*15 (4pcs)			
1963	PLMB0085#01	Bit Guide Assy for Box φ15			
1964	PLMB0085#02	Bit Guide Assy for Box φ17			
1965	PLMB0085#03	Bit Guide Assy for Box φ19			
1966	PLMB0085#04	Bit Guide Assy for Box φ21			
1967	PLM00530#01	Bit Guide for Box φ15			
1968	PLM00530#02	Bit Guide for Box φ17			
1969	PLM00530#03	Bit Guide for Box φ19			
1970	PLM00530#04	Bit Guide for Box φ21			
1971	PLM09103#01	LV Start Switch (with Harness)			
1972	LVE25-30B	Automatic Screw Feeder	3.0	Pick up box	
1973	LVE25-35B	Automatic Screw Feeder	3.5	Pick up box	
1974	LVE25-40B	Automatic Screw Feeder	4.0	Pick up box	
1975	LVE25-50B	Automatic Screw Feeder	5.0	Pick up box	
1976	LVE25-60B	Automatic Screw Feeder	6.0	Pick up box	
1977	LVE25-80B	Automatic Screw Feeder	8.0	Pick up box	
1978	LVE50-30B	Automatic Screw Feeder	3.0	Pick up box	
1979	LVE50-35B	Automatic Screw Feeder	3.5	Pick up box	
1980	LVE50-40B	Automatic Screw Feeder	4.0	Pick up box	
1981	LVE50-50B	Automatic Screw Feeder	5.0	Pick up box	
1982	LVE50-60B	Automatic Screw Feeder	6.0	Pick up box	
1983	LVE50-80B	Automatic Screw Feeder	8.0	Pick up box	
1984	LVE25-30S	Automatic Screw Feeder	3.0	Lever take out	
1985	LVE25-35S	Automatic Screw Feeder	3.5	Lever take out	
1986	LVE25-40S	Automatic Screw Feeder	4.0	Lever take out	
1987	LVE25-50S	Automatic Screw Feeder	5.0	Lever take out	
1988	LVE25-60S	Automatic Screw Feeder	6.0	Lever take out	
1989	LVE25-80S	Automatic Screw Feeder	8.0	Lever take out	
1990	LVE50-30S	Automatic Screw Feeder	3.0	Lever take out	
1991	LVE50-35S	Automatic Screw Feeder	3.5	Lever take out	
1992	LVE50-40S	Automatic Screw Feeder	4.0	Lever take out	
1993	LVE50-50S	Automatic Screw Feeder	5.0	Lever take out	
1994	LVE50-60S	Automatic Screw Feeder	6.0	Lever take out	
1995	LVE50-80S	Automatic Screw Feeder	8.0	Lever take out	

No.	Part Number	Name of Part	xx : screw size(mm)	y : Screw access gate	Z : Screw feeder model to be installed
1996	LVE25-30H	Automatic Screw Feeder	3.0	Access tray	
1997	LVE25-35H	Automatic Screw Feeder	3.5	Access tray	
1998	LVE25-40H	Automatic Screw Feeder	4.0	Access tray	
1999	LVE25-50H	Automatic Screw Feeder	5.0	Access tray	
2000	LVE25-60H	Automatic Screw Feeder	6.0	Access tray	
2001	LVE25-80H	Automatic Screw Feeder	8.0	Access tray	
2002	LVE50-30H	Automatic Screw Feeder	3.0	Access tray	
2003	LVE50-35H	Automatic Screw Feeder	3.5	Access tray	
2004	LVE50-40H	Automatic Screw Feeder	4.0	Access tray	
2005	LVE50-50H	Automatic Screw Feeder	5.0	Access tray	
2006	LVE50-60H	Automatic Screw Feeder	6.0	Access tray	
2007	LVE50-80H	Automatic Screw Feeder	8.0	Access tray	